



**Eddyfi
Technologies**
—
Beyond current

Getting Started with
ICON SOFTWARE



About This Manual	1
Specifications	1
Minimum Computer System Requirements	1
Required Folder Permissions	2
Supported Video Frame Grabbers	2
Supported Eddyfi Technologies Products	2
ICON™ Software Applications, Features and Functionality	3
Getting Started	5
Icon™ Installation.....	5
Entering the ICON™ interface	6
License Activation	6
ICON™ Control and Operations Screen	6
System Operation	8
Configuring System Devices	9
System Configuration Management	9
Import System Configuration	10
Selecting and Loading a System Configuration	10
Removing a System Configuration	11
Renaming System Configuration	11
System Components	11
Device Serial Numbers	12
Configuring a One-Button Job Start/Stop/Export Operation	12
ICON™ Configuration File Carousel	13
ICON™ Backstage	14
Events	14
Diagnostics.....	15
Communication Diagnostics- Separate Channels	15
Communication Diagnostics - Combined Channel	15
Port Percentage.....	16
Exports	16
Export Videos	17
Export Snapshots	18
User Groups.....	18
Creating A New User Group	19
Removing Or Modifying User Groups	19
Adding Or Removing Users From A Group	20
Features	20
Configurations	23
Configuring Communication Channels	24
Configuring System Devices.....	24
Video Capture Devices – Frame Grabbers.....	24
Chassis And Tracks.....	26
Actuators.....	27
Sensors.....	29
Auxiliary Lights.....	29

Discrete State Devices (Switches).....	30
Enabling/Disabling Devices	30
Renaming System Components	31
Reel Encoder	31
Plugins	32
Adding plugin Packages	32
Configuring Plugin Device	32
Removing Plugin Device.....	32
Calibration	32
Calibration Manager.....	33
Calibrating Device Feedback	33
Task Automation	34
Automation Actions	34
Automation Variables	34
Automation Rules	35
Automation Routines	36
Settings	37
Job Attributes	37
Creating Job Attributes	37
Assigning Job Attributes	38
Creating External Job Attributes	38
Using Job Attributes From An External File.....	39
Inspection Standards Manager	39
Creating Specifications Standards.....	39
Setting a Default Inspection Standard	40
Gamepad Profile Manager	40
Creating A New Gamepad Profile.....	40
Instrument Panel Manager.....	41
Creating A New Instrument Panel	41
Editing An Instrument Panel	42
Changing The Size Of A Tile	42
Changing The Colour Of The Tile	42
Binding Device Parameter To The Tile.....	43
Setting The Measurement Range For The Parameter	43
Setting A Default Instrument Panel.....	43
Control Panel Manager	44
Creating A New Control Panel.....	44
Editing A Control Panel.....	44
Changing The Size Of The Tile	45
Overlay Template Designer	45
Creating A New Overlay Template	45
Editing An Overlay Template	46
Changing The Size Of The Annotation	46
Annotation Types	46
Setting Text And Annotation Properties.....	47

Taking Snapshots 66

Setting Image Annotations Properties	48
Setting Gauge Annotation Properties	48
Preferences	49
About	50
Application Info.....	50
License Status.....	50
Licensing Models	50
Activation Modes	50
Refresh Time	50
License Release	51
Current License Information.....	51
License Agreement	51
Manuals.....	51
Elevated Permissions.....	51
Control and Operation	52
Camera Control.....	53
Video Switching	53
Camera Imager Control ZOOM	54
Focus	54
Auto Focus Sensitivity	54
Exposure.....	55
Camera Light Control.....	55
Crosshair	57
Camera Attitude Control (Pan/Tilt).....	57
Camera Set Points.....	58
Track Control.....	58
Control Modes	59
Moving & Steering	59
Emergency Stop	60
Track Reversal.....	60
Actuator Control	60
Actuator Control Modes	60
Power Control	61
Speed Control.....	61
Position Control	61
Push Button Control.....	62
Sensor Control	62
Switch Control.....	63
Switch States	63
Job Management	63
Starting a Job.....	63
Video Recording.....	64
Recording Mode	64
Available Free Space Monitor.....	65
Exporting Videos	65

Independent Snapshots	67
In-Job Snapshots	67
Export Snapshots	67
Automatic Snapshot Export	67
Manual Snapshot Export	67
Toggling Overlay.....	67
Exporting Video with Overlay.....	68
Managing Recorded Jobs	68
Deleting Recorded Jobs	68
Deleting An Individual Job	68
Deleting Multiple Jobs.....	68
Transferring Recorded Jobs	69
Exporting Jobs	69
Importing Jobs	69
Getting Job Telemetry	69
Xbox Controller	70
Connecting the Xbox Controller.....	70
Control Mapping	70
Xbox Controller Settings	71
Keyboard Control	71
Camera Keyboard Control	71
System Status Panels.....	72
ICON™ Reporting	73
Troubleshooting	73
Parts and repairs	73
Limited warranty policy	74

About This Manual	1
Specifications	1
Minimum Computer System Requirements	1
Required Folder Permissions	2
Supported Video Frame Grabbers	2
Supported Eddyfi Technologies Products	2
ICON™ Software Applications, Features and Functionality	3
Getting Started	5
Icon™ Installation.....	5
Entering the ICON™ interface	6
License Activation	6
ICON™ Control and Operations Screen	6
System Operation	8
Configuring System Devices	9
System Configuration Management	9
Import System Configuration	10
Selecting and Loading a System Configuration	10
Removing a System Configuration	11
Renaming System Configuration	11
System Components	11
Device Serial Numbers	12
Configuring a One-Button Job Start/Stop/Export Operation	12
ICON™ Configuration File Carousel	13
ICON™ Backstage	14
Events	14
Diagnostics.....	15
Communication Diagnostics- Separate Channels	15
Communication Diagnostics - Combined Channel	15
Port Percentage.....	16
Exports	16
Export Videos	17
Export Snapshots	18
User Groups.....	18
Creating A New User Group	19
Removing Or Modifying User Groups	19
Adding Or Removing Users From A Group	20
Features	20
Configurations	23
Configuring Communication Channels	24
Configuring System Devices.....	24
Video Capture Devices – Frame Grabbers.....	24
Chassis And Tracks.....	26
Actuators.....	27
Sensors.....	29
Auxiliary Lights.....	29

About 50

Reel Encoder	31
Plugins	32
Adding plugin Packages	32
Configuring Plugin Device	32
Removing Plugin Device.....	32
Calibration	32
Calibration Manager.....	33
Calibrating Device Feedback	33
Task Automation	34
Automation Actions	34
Automation Variables	34
Automation Rules.....	35
Automation Routines.....	36
Settings	37
Job Attributes	37
Creating Job Attributes	37
Assigning Job Attributes	38
Creating External Job Attributes	38
Using Job Attributes From An External File.....	39
Inspection Standards Manager	39
Creating Specifications Standards.....	39
Setting a Default Inspection Standard	40
Gamepad Profile Manager	40
Creating A New Gamepad Profile.....	40
Instrument Panel Manager.....	41
Creating A New Instrument Panel	41
Editing An Instrument Panel	42
Changing The Size Of A Tile	42
Changing The Colour Of The Tile	42
Binding Device Parameter To The Tile.....	43
Setting The Measurement Range For The Parameter	43
Setting A Default Instrument Panel.....	43
Control Panel Manager	44
Creating A New Control Panel.....	44
Editing A Control Panel.....	44
Changing The Size Of The Tile	45
Overlay Template Designer	45
Creating A New Overlay Template	45
Editing An Overlay Template	46
Changing The Size Of The Annotaion	46
Annotation Types	46
Setting Text And Annotation Properties.....	47
Setting Image Annotations Properties	48
Setting Gauge Annotation Properties	48
Preferences.....	49

Application Info.....	50
License Status.....	50
Licensing Models.....	50
Activation Modes.....	50
Refresh Time.....	50
License Release.....	51
Current License Information.....	51
License Agreement.....	51
Manuals.....	51
Elevated Permissions.....	51
Control and Operation.....	52
Camera Control.....	53
Video Switching.....	53
Camera Imager Control ZOOM.....	54
Focus.....	54
Auto Focus Sensitivity.....	54
Exposure.....	55
Camera Light Control.....	55
Crosshair.....	57
Camera Attitude Control (Pan/Tilt).....	57
Camera Set Points.....	58
Track Control.....	58
Control Modes.....	59
Moving & Steering.....	59
Emergency Stop.....	60
Track Reversal.....	60
Actuator Control.....	60
Actuator Control Modes.....	60
Power Control.....	61
Speed Control.....	61
Position Control.....	61
Push Button Control.....	62
Sensor Control.....	62
Switch Control.....	63
Switch States.....	63
Job Management.....	63
Starting a Job.....	63
Video Recording.....	64
Recording Mode.....	64
Available Free Space Monitor.....	65
Exporting Videos.....	65
Taking Snapshots.....	66
Independent Snapshots.....	67
In-Job Snapshots.....	67
Export Snapshots.....	67

Automatic Snapshot Export	67
Manual Snapshot Export	67
Toggling Overlay.....	67
Exporting Video with Overlay.....	68
Managing Recorded Jobs	68
Deleting Recorded Jobs	68
Deleting An Individual Job	68
Deleting Multiple Jobs.....	68
Transferring Recorded Jobs	69
Exporting Jobs	69
Importing Jobs	69
Getting Job Telemetry	69
Xbox Controller	70
Connecting the Xbox Controller.....	70
Control Mapping	70
Xbox Controller Settings	71
Keyboard Control	71
Camera Keyboard Control	71
System Status Panels.....	72
ICON™ Reporting	73
Troubleshooting	73
Parts and repairs	73
Limited warranty policy	74

About This Manual

This manual has been prepared to assist in the operation of Eddyfi Technologies' systems and software. Correct, prudent and safe operation rests with the operator who must thoroughly understand the operation, maintenance, service, and job requirements. The specifications and information in this manual are current at the time of printing.

ICON™ software is continually being updated and improved. This manual endeavor to explain and define the functionality of the application. Furthermore, screen shots and detailed functionality may differ slightly from what is described in this manual.

All features and functions within ICON™ software are described within this manual. The specific features available to a user are determined by the software license. Not all features are always accessible.

Eddyfi Technologies reserves the right to change and/or amend specifications at any time without notice. Clients will be notified of any changes to their equipment. Information in this manual does not replace specific regulations, codes, standards, or requirements of others such as government regulations.

This manual copyright ©2021 by Eddyfi Technologies Inc. All rights reserved.

Specifications

ICON™ software was created to provide device control and data gathering capabilities for Eddyfi Technologies Crawlers and Camera Systems using a Windows™ based computer.

Minimum Computer System Requirements

Processor	Sixth generation Intel® Core i5 or greater
Graphics	Intel® UHD 620 or greater with Intel® Quick Sync enabled DirectX 11 or higher compatible
RAM	8 GB minimum
Application Disk Space	30 GB minimum (for application installation and database)
Data Disk Space	>500 GB for visual inspection data (separate system and data HDD or SSD with 3.0 GB/s access speeds recommended)
Operating System	Windows™ 10 (Professional recommended)
Screen Resolution	1920 x1080 minimum

Note: ICON™ is a resource intensive application; other applications may also consume resources and as a result they may interfere with the operation of ICON™.

Note: Requirements are subject to change based on system requirements and configuration. Support for systems not meeting recommended minimum specifications may be refused.

Required Folder Permissions

The ICON™ software keeps multiple important files in C:\ProgramData\ICON 4\ folder. As known, the Windows NTFS file system applies permissions to every file and folder. The lack of permissions can cause the Access Denied error to occur and the application to stop functioning.

To avoid this, make sure all users supposed to work with ICON™ have Full Control permissions on that folder. The way of how to achieve this depends on the current PC and network configuration. In the simplest cases, complete the following steps:

1. Navigate to **C:\ProgramData\ICON 4**.
2. Right-click on the folder, select Properties, and then the Security tab.
3. Check/add all the users and allow them Full Control permission.

Note: The folder C:\ProgramData is a hidden folder, so ensure that the Hidden Items checkbox is checked in the File Explorer View tab. Please contact your System Administrator in case of any issues.

Supported Video Frame Grabbers

The following video capture devices are supported by ICON™:

- Black Magic
- Epiphan AV.io SDI
- Magewell USB Capture Plus frame grabber family

Note: Ensure that the requirements specified by the frame grabber manufacturer meet the system requirements.

Supported Eddyfi Technologies Products

The ICON™ software has been developed to support Eddyfi Technologies devices and inspection systems including but not limited to:

- Picotrac™
- 4000 series Microtrac™
- 8000 series Minitrac™
- Spectrum™ 45 PT Inspection Camera
- Spectrum™ 90 PTZ Inspection camera
- Spectrum™ 120 PTZ Inspection Camera
- STIK™ Inspection Camera System

- LineTrax™ 50 Pipe Inspection Crawler
- LineTrax™ 100 Pipe Inspection Crawler
- LineTrax™ 150 Pipe Inspection Crawler

- TriTrax™ 200 Pipe Inspection Crawler
- TriTrax™ 380 Pipe Inspection Crawler
- TriTrax™ 205Pipe Inspection Crawler
- TriTrax™ 320 Pipe Inspection Crawler

- NanoMag™ Miniature Magnetic Crawler
- Magg™ 310 Inspection Crawler
- Magg™ 480 Inspection Crawler
- All Custom Systems

ICON™ Software Applications, Features and Functionality

The features and functionality associated with the different application tiers of ICON™ software are detailed in Table 1. When ICON™ software is first installed, a 15-day trial license may be granted for evaluation purposes. Contact Eddyfi Technologies if the trial license is required. The software will no longer be fully functional after 15 days and a valid license key must be entered for full activation. Once the software is activated with the appropriate license key, the software will expose the licensed features to the user based on Table 1 - ICON™ Software Features and Functionality. Primary applications included with ICON™ software are:

ICON™ Diagnostics	A free application installed through its own installation package or be a module for all ICON™ Licensed Tiers. Users can connect a single device at a time for calibration, diagnostics, and configuration purposes.
ICON™ Licensed Tiers	Represents a licensed functionality tier that includes all the primary ions used to configure, control, and report. Available tiers include:
ICON™ CPN	Companion. Single system configuration with a single camera plus a tether encoder, with no advanced features.
ICON™ STD	Standard. Single system configuration with up to two Microtrac or three Picotrac tracks, actuators, multiple cameras, sensors plugins and running predefined automation routines and alarms.
ICON™ PRO	Professional. Fully featured use of multiple configurations, supports large class and custom vehicles, configurable control panels, configure and run automation routines and alarms.

Access restricted to one device ● Availability determined by system configuration ● Feature available

Table 1 - ICON™ Software Features and Functionality		ICON™ Diagnostics	ICON™ CPN	ICON™ STD	ICON™ PRO
Configuration Management					
Configuration Management			●	●	●
Multiple Configurations					●
Device Control					
Track Control	○			●	●
Single Camera Control	○	●	●	●	●
Multiple Camera Control				●	●
Auxiliary Light Control	○			●	●
Actuator Control	○			●	●
Sensor Control	○			●	●
Discrete State Device Control	○			●	●
Plugin Control				●	●
Device Calibration	○			●	●

Video				
Single Camera Video Viewing	○	●	●	●
Multiple Camera Video Viewing			●	●
Picture-In-Picture Viewing			●	●
SD Video Recording		●	●	●
HD Video Recording		●	●	●
Video Overlay Templates		●	●	●
Data Retention				
Managed SQL Database		●	●	●
Job Management				
Export Job File (.i Job) for Data Transfer Between Systems			●	●
Multiple Video Recordings per Job		●	●	●
One-Click Job Start/Stop		●	●	●
Automatic Background Export of Video		●	●	●
Automatic Export of Snapshots		●	●	●
Save Snapshots to Job Database		●	●	●
Tag Snapshots		●	●	●
Tag Snapshots with Inspection Codes			●	●
System Management				
ICON Device Manager		◐	◐	●
System Preferences		◐	●	●
Configurable Job Attributes			●	●
Plugin Device Manager for Add-on Plugin Modules			◐	●
Configurable Gamepad Profiles		●	●	●
Configurable Instrument Panel			●	●
Configurable Control Panel				●
Communication Diagnostics	○	●	●	●
Import Inspection Standards			●	●
Control and Operations				
Support for Multiple Displays			●	●
Instrument Panel			●	●

Keyboard Control		●	●	●
Mouse Control		●	●	●
Touch Screen Control		●	●	●
Gamepad Control		●	●	●
Predefined Automation Routines			●	●
Configurable Automation Routines				●
Customized Access Groups			●	●
Windows™ Local User Credentials			●	●
Windows™ Domain User Credentials			●	●
License Management		●	●	●
Notification and Alarm Management				
System Notifications		●	●	●
Predefined Alarms			●	●
Configurable Alarms				●
Reporting				
Customizable reporting using SQL SSRS				●
SSRS Job Report Output in PDF Format				●
SSRS Job Report Output in WORD Format				●

Access restricted to one device ● Availability determined by system configuration ● Feature available

Getting Started

The Getting Started section is intended to get the software operational with basic functionality. It is advised that you read the entire user manual for detailed application set-up and operation. Topics covered in this section include:

- ICON™ Installation
- Importing System Configuration(s)
- Entering the ICON™ Interface
- Instrument Panel Configuration
- One-Button Start/Stop/Export
- Game Pad Control
- Keyboard Control

Icon™ Installation

The following steps will provide you with the instructions to install the ICON™ software.

1. Download and launch the installer executable. The Inuktun ICON™ can be downloaded from

2. <https://eddyfi.com/en/software/inuktun-icon>
3. Install the prerequisite software packages as directed by the installation wizard.
4. Select the desired ICON™ packages for installation.
5. Click Finish.

Entering the ICON™ interface

A configuration file is required to operate an Eddyfi Technologies inspection system through ICON™ software. Before starting ICON™, acquire the system configuration files (*.icfg) for your specific inspection system(s) from Eddyfi Technologies.



DEFAULT CONFIGURATION

Once the ICON™ software is installed, the default single-web-camera configuration is available.

There are three ways to enter the ICON™ operations screen once the installation process is complete and a system configuration has been added. The options are:

- Wait for the highlighted ICON™ configuration to start automatically after ~30 seconds.
- Navigate to the desired ICON™ configuration and double-click to start.
- Right-click the ICON™ configuration and select Start from menu.


License Activation

ICON™ software requires a license for each computer it is installed on. When the application is first installed, it is not activated and requires a valid license code to start functioning. A 15-day trial license can be granted for evaluation purposes. The software has limited functionality in this mode and will no longer be fully functional after 15 days and a valid license code must be entered for full activation.

Please refer to 'ICON – Nalpeiron Desktop License Activation & Software Updates' manual for more detail about licensing management.

ICON™ Control and Operations Screen

The Control and Operations Screen consists of the various panels, elements and regions used for control and operation of an Eddyfi Technologies inspection system. The main window is divided into multiple sections with various operational elements. See the Control and Operation Screen table for further detail on each section.



CONTROL AND OPERATIONS SCREEN

Note: The above Control and Operations Screen may differ depending on the system configuration. The will be the same for all system.

SCREEN ELEMENT	FUNCTION
Control Panel	Contains the configured control elements used to operate specific system devices such as Tracks, Cameras, Lights, Actuators, and so on.
Control Ribbon	Displays control elements for the specific selected device in the control panel.
Video Panel	Displays live video from the currently selected camera. Camera selection can be changed on the Control Ribbon if more than one camera is available.
Notification Tabs	Displays the number of current notifications grouped by their category and importance/severity. Clicking on any tab will open the notification panel for the appropriate category.
Status Panel	Displays system status information.
Instrument Panel	Live data from the system is displayed on the instrument panel. The content of the instrument panel is configured in Backstage through the Instrument Panel Manager.
Extended Instrument Panel Button	When the extended instrument panel is configured, instruments will be overlaid onto the video panel when toggled.

SCREEN ELEMENT	FUNCTION
Job Start/Stop Button	Starts/Stops a Job. All data, videos, and snapshots are stored in the ICON™ Suite database within the context of a Job. A simplified one-button start/stop/export can be configured within ICON™ to streamline operator workflow. Refer to the Configuring One-Button Start/Stop/Export Operation section for more detail.
Automation Viewer Button	If available, toggles the Automation Viewer to start/stop automation routines.
Video Panel Dock/Undock Button	This button is used as an option to undock the video panel. The video panel can then be placed on a secondary monitor or re-docked at any time.
Backstage Button	Backstage button toggles between the main control screen and the ICON™ Backstage configuration utility

System Operation

The Control Panel on the left side of the Control and Operations Screen contains the devices available to be controlled for a specific system as determined by the configuration file.

Selecting a device in the Control Panel will activate control for that device and will toggle the Control Ribbon (above) for the device's secondary properties.

With a selected device active, the primary device parameters are controlled on the Control Panel. Secondary properties are displayed and can be adjusted on the Control Ribbon.

Example:

A single axis camera is selected as the active control device. In the Control Panel, the user can control:

- Camera Zoom- Left Slider
- Camera Position - Middle Slider
- Camera Lights - Right Slider


Secondary camera properties such as: Focus, Exposure, Lasers, Defog, and Lowlight are selected and controlled on the Control Ribbon.



Configuring System Devices

System Configuration Management

A configuration file is required to operate an Eddyfi Technologies inspection system using ICON™ software. The configuration file essentially defines the composition, communication, and control elements associated with a specific inspection system. Multiple configurations can be imported depending on software license capabilities. ICON™ software provides a tool to deal with multiple system configuration or with a single one if this is determined by the software license.





SYSTEM CONFIGURATION MANAGER

Import System Configuration

To import system configurations from the configuration file associated with your Eddyfi Technologies system, complete the following steps

6. Navigate to Backstage -> Configurations.

1. Click  Import Configuration button at the bottom of the manager to show the import dialog box.
2. Select the configuration file (*.icfg)
3. Once the file has been selected, select a configuration(s) to be imported, and click the OK button to complete the selection.



SELECTING A SYSTEM CONFIGURATION


Note: *If the software license does not have the Multiple Configurations feature, the confirmation dialog box will pop up to confirm replacing the only existed configuration.*

Selecting and Loading a System Configuration

The selected and loaded system configuration is always marked by the checked sign. By default, the last previously selected configuration is selected again to enter ICON™ interface. This can be changed, refer to the User Group section for more detail.



THE SELECTED CONFIGURATION MARK



THE CONFIGURATION SELECTION CHECKBOX

To select and load another configuration, click on its title and then on the check box to the left of it. Finally confirm the choice in the confirmation dialog.

Removing a System Configuration

To remove a system configuration, click the trash icon button beside its name and confirm the action.

Note: Only a not selected and loaded system configuration can be removed.

Renaming System Configuration

ICON™ allows to import the same configuration multiple times. All of them will have the same title defined in their configuration files. The title can be changed, however, if needed.


To rename a configuration complete the following steps:

1. Navigate to Backstage -> Configurations.
2. Select a configuration from the configuration list.
3. Click pen icon to start editing.
4. Enter the desired title. It is recommended to keep it concise and descriptive. When completed, click either to save or delete to cancel the changes.

System Components

After a new system configuration has been added to ICON™, some setup of the system devices is required. Setup of system devices is performed in the Backstage configuration manager through Configurations.

Configurations will provide some guidance as to which properties need to be completed by highlighting the missing information with a red outlined box. The system configuration will determine which items need to be configured or filled in. All outlined areas will need to be completed before a system is fully operational. Refer to the System Components section for greater detail on system configurations and setup.



SYSTEM COMPONENT CONFIGURATION

Note: Only a selected and loaded system configuration can be configured. The setting for other unloaded configurations, however, can be observed by selecting a configuration and one of its components.


Device Serial Numbers


Each Eddyfi Technologies Device is programmed with a serial number from the factory. This serial number must be system unique or the system will not work. If a duplicate serial number is found, the serial number can be changed using ICON™ Diagnostics.

Entering a device serial number, is as follows:

1. Navigate to Backstage -> Configurations.
2. Select the device from the list of System components.
3. Click Edit.
4. Enter in the space provided or pick up from the drop down list the Device Serial Number.
5. Click Save

Note: Serial numbers are case sensitive.

To see the list of available serial numbers in the drop down list, it is strongly recommended to set up communication channels Port Name properties first. To refresh the list, click  beside the drop down list.



DEVICE SERIAL NUMBER ENTRY

Configuring a One-Button Job Start/Stop/Export Operation

The One-Button Start/Stop/Export configuration allows for a simplified inspection workflow. This is one example of how workflow can be optimized for a streamlined inspection process. The One-Button Start/Stop/Export configuration uses the following workflow:

- A Job is started using the Start Job button. The Job gets named, then the video automatically starts recording.
- The user controls the system and performs an inspection. Snapshots and video tags may be used.
- The Job is stopped when inspection is complete. The stop action automatically exports the video and snapshots to the export folder.

Note: Multiple video sources can be configured to start recording at the same time.


Below is an example of a One-Button Start/Stop/Export configuration work flow. Refer to the relevant sections of this manual for more detailed information.

1. Navigate to Backstage -> Settings -> Preferences.

2. Toggle the Enable Automatic Video Export and Enable Automatic Snapshot Export to ON.
3. In Configurations -> Selected Configuration -> System Components, select Camera, then
4. In User Groups -> Selected User Group -> Features, select Job Management, then toggle to OFF Enable Video Controls.




PREFERENCES FOR ONE-BUTTON ACTIONS



SETTING DEFAULT RECORDING FOR ONE-BUTTON START/STOP/EXPORT

5. The One-Button Start/Stop/Export configuration is now set. This type of configuration can vary depending on desired operation or level of user permissions. This is one of the many types of configuration setups that can be implemented in ICON™ software.



DISABLING VIDEO CONTROLS FOR ONE-BUTTON START/STOP/EXPORT

ICON™ Configuration File Carousel

The Configuration Carousel will appear each time ICON™ software starts. This is where system configurations can be alternatively selected when entering ICON™ interface. Its appearance depends on the number of configurations have been imported. In case of one or two configurations, to switch between them, just click on the desired one. In case of three or more, use a mouse scroll or click the yellow arrow buttons.



SYSTEM CONFIGURATION START-UP SCREEN


After selecting a desired configuration, enter the ICON™ interface as described in the **Getting Started -> Entering the ICON™ Interface section**.

ICON™ Backstage

In the About section, operators can find information about ICON™ and its activation status, as well as access the user manual. ICON™ Software Licensing and Elevated Permissions are also managed in this section.

Events

The Event Viewer contains valuable information regarding the current system configuration in use. Notifications are helpful when setting up a system, as well as troubleshooting system errors. For convenience, events are split into three categories: errors, alarms, and messages.



EVENT VIEWER


There are two ways to access the Event Viewer. By selecting Backstage button and then the Events tab, or by clicking one of the three Events tabs labelled; Errors, Alarms, and Messages, at the right side of the main window, then, when the Event Panel slides in, by clicking the Event Viewer button at the bottom-right of the panel.

When accessing the Event Viewer from the main window or in case of clicking on any other part of the application, the Event Panel will slide out to the left. You can clear events from the Panel by selecting Clear All or individually, by clicking the Delete button.

Note: The Event Panel on the right side displays only runtime events. They can appear and disappear as the application keeps running. Clearing or deleting events from the panel does not affect the application event history.

The Event Viewer displays this history. Automatically events are loaded just once when the application starts and then

must be refreshed manually by clicking on the Refresh button. The events can be filtered by a category, dumped into a file for diagnostic and troubleshooting purposes, or cleared events away from the history by clicking on the appropriate button.




BACKSTAGE EVENT VIEWER

Diagnostics

Communication Diagnostics provide information on the status of system communication tasks. A system may utilize multiple communication channels, depending on complexity. Each communication channel may have multiple tasks associated with it. Communication channels can be viewed separately through the Separate Channels tab or combined through the Combined Channel tab. Separate Channels will show all the tasks associated with that channel. Combined Channel will show all the channels and the tasks will be combined.

Communication Diagnostics- Separate Channels

The Separate Channels view is divided into three main headings: Task, Progress, and Port %. At the bottom left are the active communication channel tabs. Select between the tabs to view channels individually. Tasks will be displayed for that specific channel.



COMMUNICATION DIAGNOSTICS - SEPARATE CHANNELS PAGE

Communication Diagnostics - Combined Channel


The Combined Channel view is divided into four main headings: Communication Channel, Task, Progress, and Port %. Tasks are combined and the overall communication information will be displayed for all channels.

Communication Diagnostics			
Communication Channel		Task	Port %
Communication Channel	CONTROL TASK: Chassis	-	19.1%(98.3%)
Communication Channel	CONTROL TASK: Wrist Continuous Actuator	-	18.5%(99.8%)
Communication Channel	CONTROL TASK: Gripper Continuous Actuator	-	19.4%(100.0%)
Communication Channel	OPERATION TASK: Camera Feed Interface: 01 Method: 00 SubComponent: 00	-	22.9%(99.9%)
Communication Channel	OPERATION TASK: Chassis Interface: 01 Method: 00 SubComponent: 00	-	6.1%(99.9%)
Communication Channel	OPERATION TASK: Wrist Continuous Actuator Interface: 01 Method: 00 SubComponent: 00	-	3.1%(99.7%)
Communication Channel	OPERATION TASK: Gripper Continuous Actuator Interface: 01 Method: 00 SubComponent: 01	-	3.0%(99.8%)

COMMUNICATION DIAGNOSTICS - COMBINED CHANNELS PAGE

Port Percentage

There are two pieces of information associated with the Port % tab. The first percentage, on the left, is the channel utilization rate of a task. This is the percent of communication packets received through that channel. The sum of the task percentages on a channel theoretically add up to 100%. The second percentage, on the right, is the success rate of the task. The task is completing successfully, indicated by 100%.




PORT PERCENTAGE

Exports

The Video Export manager is used to review, export, and delete recent and past recorded Jobs as well as their videos and snapshots. By default, all Jobs Made Within Current Session will be displayed on the Recorded Jobs panel. The dropdown menu also allows selection between Jobs Made Today and All. A selected Job video and snapshots will be displayed on the Job Videos and Job Screenshots panels accordingly. Displayed information includes the camera name, date, and time of the beginning of recording, duration, resolution, frame rate (fps), and data rate (kbps).


Note: Please refer to the Job Recording section in this manual for detailed instructions.



VIDEO EXPORT PANEL

Export Videos

To select a video, click on its title. The tile will expand and show export parameters panel.



VIDEO EXPORT PARAMETERS PANEL

Three video export modes are available:

- Original Video (no changes in the video)
- Formatted Video (the video is formatted into one of the following formats)
 - Same as Source
 - NTSC
 - PAL
 - o1080i 59.94 fps
 - o1080i 30.00 fps
- Template Annotations

To export a video, complete the following steps:

1. Select the desired video export mode.
2. Select the desired format if Formatted Video is selected or the desired overlay template if the option is Template Annotations. Refer to the ICON™ Backstage -> Settings -> Overlay Templates for details.
3. Select the export file location. If not selected, the default value defined in Preferences -> Set Default Export Location is used.
4. Select the desired export bit rate, the higher the value the higher the quality but it takes more disk space.
5. Click the Export button to export a video file.

Notifications about video export status will pop up on the screen. The status of the video export can be also observed on the Status tab of the same panel. It is possible to see the progress of the video export process or cancel the export if needed.




VIDEO EXPORT STATUS PANEL PARAMETERS PANEL

The exported video can be found at the defined location.

Export Snapshots

Like videos, to select a snapshot, click of its title. The tile will expand and show export parameters panel. To export a snapshot, just click the Export button and select a destination folder. The exported snapshots can be found at the defined location.



SNAPSHOT EXPORT PARAMETERS PANEL PARAMETERS PANEL

User Groups

The Group Manager is a tool that allows administrators to create and manage user groups with different access levels. User groups allow an administrator to enable or disable certain features for use within ICON™ for specific groups of users.

The Group Manager is used to manage user groups, allowing different accessibility for different categories of users. When installing ICON for the first time, the special ICON™ Administrators group with the only user (the current one) is


created. This group is locked, has all permissions, and cannot be deleted. It must also have at least one user inside.

Note: The feature access management can only be accessed by ICON™ Administrators.


Creating A New User Group

To create a new user group, complete the following steps:

1. Navigate to: Backstage -> User Groups.
2. Select New Group.
3. Enter Group Name, Group Description, and select a Default Configuration.
4. Save



USER GROUP MANAGER



CREATING A NEW USER GROUP

Note: A default configuration specifies which configuration is pre-selected on the ICON™ Configuration Carousel. It allows to simplify the search of the desired configuration. If the value is set as None, the last previously selected configuration is selected again to enter ICON™ interface.

A new group will be created, and Group Features will then be active for configuration purposes.

Removing Or Modifying User Groups


To remove a user group, click the Delete button. A pop-up window will ask for confirmation. Select OK. To modify group

names, descriptions, or default configurations, click the Edit button. Select Save when complete.

Adding Or Removing Users From A Group

To add a user to a user group, complete the following steps:

1. First select the user group to which members are to be added.
2. Select a domain and then a domain group.
3. Add either the entire group by clicking on the Add Group button or select members to be added and click the Add Members button.
4. To remove group members, select all of them checking the All checkbox or select individual members, and click on the Remove button.
5. Click Save.



ADDING / REMOVING USER GROUP MEMBERS

Features

This tab allows the administrator to enable or disable features and control feature attributes for the selected user group under the User Groups section.

Automation Group

Automation Designer - This option allows the operator to create and modify automation rules and routines.

- Enable Create and Edit Automation Routine – Allows the operator to create and edit automation routines.
- Enable Create and Edit Automation Rule – Allows the operator to create and edits automation rules.

Automation Runtime - This option allows the operator to use existing automation rule and routines.

- Enable Import Automation Module – Allows the operator to import automation rules and routines.
- Enable Delete Automation Module – Allows the operator to delete existing automation rules and routines.
- Enable Run Automation Routine – Allows the operator to run automation routines.
- Enable Toggle Rule – Allows the operator to enable/disable automation rules.

Configuration Management Group

Configuration Management-This option allows the operator to deal with system configurations.

- Enable Configuration Management – Allows the operator to import or delete configurations.
- Enable Modification of Runtime Properties – Allows the operator to modify the current configuration's run-time properties.
- Enable Modification of Tunable Properties – Allows the operator to edit the current configuration's tunable properties.

Multiple Configurations - This option allows the operator to switch between different configurations.

Plugin Management - This option allows the operator to use external plugins.

Enable Plugin Management – Allows the operator to add or removes plugins to/from the current configuration.

Enable Modification of Plugin Properties – Allows the operator to edit plugin properties.

Note: If both the Enable Configuration Management and Multiple Configuration are disabled, the system configuration start-up page will be skipped at start-up.

Device Control Group

Actuator Control - This option allows the operator to control actuators.

Auxiliary Light Control - This option allows the operator to control auxiliary lights.

Camera Control - This option allows the operator to control cameras.

- Enable Pan/Tilt Adjustment – Allows the operator to control a camera's Pan and Tilt Action.
- Enable Setting of Position Points – Allows the operator to work with a camera's set points.
- Enable Zoom Control – Allows the operator to control a camera's zoom.
- Enable Light Intensity Control – Allows the operator to control a camera's light intensity.
- Enable Focus Mode Control – Allows the operator to control a camera's focus mode.
- Enable Auto Focus Sensitivity – Allows the operator to change a camera's focus sensitivity.
- Enable Exposure Mode Control – Allows the operator to adjust a camera's exposure mode and level.
- Enable Individual Light Control – Allows the operator to enable or disable an individual light on the camera.
- Enable Laser Control – Allows the operator to enable or disable the laser light on the camera.
- Enable Defog Control – Allows the operator to turn on or off the camera's defogging function.
- Enable Image Stabilization – Allows the operator to turn on or off camera's image stabilization function.
- Enable Low Light Compensation – Allows the operator to turn on or off camera's image low light compensation.
- Enable Display Crosshair – Allows the operator to turn on or off a display's crosshair.

Device Calibration - This option allows the operator to calibrate sensors and actuators (if applicable).

- Enable Device Calibration – Allows the operator to calibrate device feedback.
- Enable Device Offset Setting – Allows the operator to change device feedback offset values.

Gamepad Control - This option allows the operator to control the system via Microsoft Xbox gamepad controller.

- Enable Editing of Gamepad Profiles – Allows the operator to edit the gamepad key mappings.

Sensor Control - This option allows the operator to control sensors.

Switch Control - This option allows the operator to control switches, solenoids, and relays.

Track Control - This option allows the operator to control chassis.

Inter Application Interactions Group

Application Programming Interface - This option allows the operator to invoke some ICON Software functions remotely.

- Enable Toggle API – Allows the operator to turn the API on and off.
- Enable Modification of API Properties – Allows the operator to edit the API properties and settings.
- Live Video Streaming - This option allows the operator to transmit live video from vehicle cameras over the Internet.
- Enable Toggle Video Streaming - Allows the operator to turn the video streaming on and off.

- Enable Modification of Video Streaming Properties – Allows the operator to edit the video streaming properties and settings.

Job Management Group

Inspection Code Management - This option allows the operator to edit and manage inspection codes that will be assigned to a Job.

Job Attributes Management - This option allows the operator to edit and manage attributes that will be assigned to a Job.

Job Management - This option allows the operator to create and manage jobs.

- Enable Video Controls – Allows the operator to manually start or stop video recording.
- Enable Picture Snapshots – Allows the operator to take snapshots.
- Enable Picture Independent Snapshots – Allows the operator to take independent snapshots.
- Enable Snapshot Tag Data Entry – Allows the operator to tag snapshots during a recording.
- Enable Editing of Overlay Template – Allows the operator to edit overlay layer template to be added to the exported videos.
- Enable Multiple Displays – Allows the operator to enable or disable picture-in-picture display mode.
- Enable Video Export on Export Page – Allows the operator to manually export videos with multiple options and save them as video files.
- Enable Snapshot Export on Export Page – Allows the operator to manually export snapshots and save as image files.
- Enable All Job on Export Page – Allows the operator to see all the historical Jobs in Video Export Manager. This option will be hidden in the dropdown menu when disabled.
- Enable Job Deletion on Export Page – Allows the operator to delete historical Jobs through the Video Export Manager.

Note: When this feature is off, the video recording function will be set to simplified mode. By contrast, when this feature is on, it will be set to advanced mode. Refer to the Job Recording -> Video Recording section, for more details.

Job Transfer - This option allows the operator to transfer job among computers.

- Enable Job Import on Export Page – Allows the operator to import Job files (*.ijob) which have been exported from another ICON™ system.
- Enable Job Export on Export Page – Allows the operator to export recorded Jobs into encapsulated Job files (*.ijob), which can be saved in any storage location, so user may transfer Jobs among computers.

Licensing and Access Management Group

USER ACCESS

Feature Access Management - This feature allows the operator to provide access to specific features for various groups.

User Group Management - This option allows the operator to manage groups and their members.

- Enable Editing of User Groups – Allows the operator to edit user groups and user group features.
- Enable Editing of User Group Members – Allows the operator to edit existing user group.

Notification Management Group

Notification Management - This option allows the operator to read detailed error information, export error logs, and manage notifications from the Notification Manager.

Preference Management Group

Control Panel Adjustment - This option allows the operator to work with control panels and select templates, rearrange, or resize control panel tiles.

Instrument Panel Adjustment - This option allows the operator to work with instrumental panels and edit, select templates, rearrange, or resize instrument panel tiles.

Multiple Displays - This option allows the operator to undock the ICON display and move to another monitor.

Preference Management - This option allows the operator to make changes to the global system preferences.

Configurations

The System Configuration Manager is used to manage system configurations, set up serial communication, initialize devices, edit parameters, and enable/disable devices. The manager is divided into three sections:

- The list of system configurations
- The list of system components of the selected configuration
- The list properties of the selected system component

Refer to Getting Started -> System Configuration Management to learn more about managing the configuration list.

When a new system configuration has been added to ICON™, some initial device setup is required. When setting up inspection system devices, the ICON™ System Configuration Manager will provide some guidance as to which remaining properties have issues, by highlighting them with a red box. The system configuration determines which items need to be configured. All outlined areas need to be completed before a system can be initialized. It is recommended to configure communication channels first.

ICON™ validates the system settings and, if it detects any changes and determines there are no issues, the system communication is restarted automatically when the backstage is closed. The communication can also be restarted manually by clicking on the Reset Communication button at the top left corner.

All system properties are split into three categories by their access level: run-time, tunable, and factory.

- **Run-time Property** – Has no initial value, must be set before starting operation, the operator must have Enable Modification of Runtime Properties feature enabled.
- **Tunable Property** – Has the default initial value which can be changed if needed the operator must have Enable Modification of Tunable Properties feature enabled.
- **Factory Properties** – Has the locked factory values, cannot be changed, given for information and diagnostic purposes only.




SYSTEM COMPONENT PROPERTY CATEGORIES PARAMETERS PANEL

Note: Not all three categories are always presented for a system item. Some may have just two or even one. Describes only run-time and tunable properties, which can be set through ICON™ interface.

Configuring Communication Channels

Note: Device communication setup may differ depending on the type of system configuration.

1. Navigate to Backstage -> Configurations -> Selected Configurations -> System Components.
2. Select the channel to be configured.
3. Click Edit.
4. Select the appropriate port from the dropdown menu. Use ICON™ Diagnostics to identify which port is associated with a given device.
5. Click save



COMMUNICATION CHANNEL SETTINGS

Note: Each communication channel must have a unique COM port number. The red error border appears to indicate the duplication.

Configuring System Devices

System Configuration Manager is where all devices can be enabled or disabled and where the properties of these devices can be edited. Under the title of each device, subcomponents of the device properties can be configured. The following sections detail various system device setup and configurations such as cameras, frame grabbers, tracks, and actuators.

Note: Depending on the type of system, there may be other system devices not mentioned in the section below. However, setting up system devices will follow the same format for all devices.

Video Capture Devices – Frame Grabbers

Frame grabbers are key devices for video capture, processing, and storage. ICON™ supported frame grabbers include:

Black Magic	Used on High Definition Systems
Epiphan AV.IO	Used on High Definition Systems
Magewell	Used on Standard and High Definition Systems


Frame Grabber Properties

Grabber Device	Defines a specific frame grabber
Video Format	Defines a video format for the selected frame grabber
Video Quality	Defines a video file bitrate and required disk space, 15 % recommended as default

Note: Refer to the Frame Grabber Table below for parameters when configuring frame grabbers. Frame grabber configuration steps:

Frame grabber configuration steps:

1. Select Capture Device, and then click Edit.
2. Select the appropriate Grabber Device and Video Format for it from the drop down menu.
3. Select the appropriate video quality.
4. Click Save and navigate to the Control and Operations Screen. The system will initialize automatically.



VIDEO GRABBER CONFIGURATION

Note: Only Eddyfi Technologies supported video formats can be selected from the list.

Table: Frame Grabber Parameter Settings

	Black Magic	Magewell	Epiphan
Frame Grabber Device	Intensity Pro	Magewell DVI+/SDI+	AV.IO SDI Video
Video Format (Recommended)	NTSC UYVY 720x480@29.97ib 4:3 PAL UYVY 720x576@25.00iT 4:3 1080i59.94 1080P29.97	Full HD HD SD	YUY2 1920x1080 @60.00P 16:9

Cameras

Cameras are key devices for electronic motion picture acquisition. The type of camera depends on the current configuration. They can dramatically vary by functionality, shapes, and sizes.


Camera Properties:

Default Recording	Defines if the camera starts recording automatically when the operator starts a Job
Camera Address	Defines the camera communication address
Video Channel	Defines the camera output channel
Video Signal	Defines the camera video signal type
Camera Address / Serial Number	Defines the camera communication address / Defines the camera serial number (can be found on a sticker located on the camera)

Camera Configuration Steps

1. Select the camera from System Devices.
2. Click Edit to start configuration.
3. Toggle the Default Recording option to ON or OFF.
4. In case of Camera Address, set it to C2 for the only camera in the system or for the camera with pan and/or tilt functionality.

For all the rest cameras, the value must be incremented by one (C3, etc.). In case of Serial Number, enter or select from the drop down list the camera Serial Number. Set Video Channel to Channel One (works in most cases)



CAMERA CONFIGURATION

5. Set Video Signal to Differential (works in most cases).
6. Click Save.

Note: Each camera must have a unique address / serial address. The red error border appears to indicate the duplication.

Chassis And Tracks

Chassis are composite devices which may consist of two and more tracks. Chassis settings are broken down into two sections, Track Properties and Chassis Properties

Track Properties


Serial Number	Defines the track serial number (can be found on a sticker located on the track)
Is Reversed	Defines a direction of the track
Track Type Chassis Steering Mode	Defines a track type Defines the chassis steering mode: in Crawler Steering mode, there is no need to apply throttle to turn; in Throttle Steering mode, the crawler cannot turn without moving forward or backward.

Chassis Properties

Row Differential	In case a chassis has more than one row of tracks, defines the ratio of how much slower the rear row is compared to the front one (where 0 is no difference)
------------------	--


Track Configuration Steps

1. Select the track from System Devices then click Edit.
2. Enter or select from the dropdown list the track Serial Number.
3. Check the Track Column to confirm the track direction. Normally, “0” represents the Left Track, “1” represents the Right Track.
4. For the Left Track, set Is Reversed to OFF. For the Right Track, set Is Reversed to ON.
5. Click Save




TRACK CONFIGURATION

6. Repeat steps for the remaining tracks.

Note: Each device must have a unique serial number. The red error border appears to indicate the duplication. Click  to refresh the list of detected serial numbers.

Chassis Configuration Steps

1. Select Chassis, and then click Edit.
2. Select a steering mode.
3. If it has just one row, set Row Differential to 0; otherwise, set it to 0.15.
4. Click Save.
5. Check how the chassis is controlled and steered. Repeat steps if needed.



CHASSIS CONFIGURATION

Actuators

Actuators are components of a system that move or control other mechanisms. Examples of actuators are camera raise mechanisms, sensor probe servo motors, manipulators, etc. Some actuators can have feedback parameters, some can have outputs. Both feedback parameters and outputs allow the operator to control the actuator state (motor current, actuator position, and speed are among the most common). The feedback parameters are factory settings and cannot be changed. The output, by contrast, can be modified by the operator. They extend the feedback parameters by perform-


ing some calculations defined by their mapping functions.


Actuator Properties

Serial Number	Defines the actuator serial number (can be found on a sticker located on the actuator)
Arguments	Not applicable now
Is Reversed	Defines a direction of the actuator
Outputs	Defines mapping functions and units for outputs

Actuator Configuration Steps:

1. Select the actuator from System Devices, and then click Edit.
2. Click Edit to start configuration.
3. Enter or select from the drop down list the actuator Serial Number.
4. Reverse the rotation direction if applicable


Note: Each device must have a unique serial number. The red error border appears to indicate the duplication. Click  to refresh the list of detected serial numbers.



ACTUATOR CONFIGURATION

5. For every output, click editing icon to start editing. Enter the desired mapping function referring to feedback parameters according to their order in the list (F1, F2, etc.). When completed, click the save icon to save or **X** icon to cancel the changes. For example, a mapping function provided above converts the actuator's angular rotation speed unit from degrees per second to revolutions per minute.

6. Save



ACTUATOR OUTPUT CONFIGURATION

Note: Mapping functions can significantly vary depending on many factors. It is not recommended changing them without

consulting with Eddyfi Technologies qualified personnel first.

Sensors


Sensors are devices or modules that detect events or changes in its environment and send the information to the system. Examples of sensors are reel distance encoders, orientation, radiation, pressure detectors, etc. Same as actuators, some sensor can have feedback parameters, some can have outputs. The configuration of outputs is similar to actuator feedback and output configuration. Refer to the Actuators section for more detail.

Sensor Properties


Serial Number	Defines the actuator serial number (can be found on a sticker located on the actuator)
Outputs	Defines mapping functions and units for outputs

Sensor Configuration Steps:

1. Select the sensor from System Devices.
2. Click Edit to start configuration.
3. Enter or select from the dropdown list the sensor Serial Number.

Note: Each device must have a unique serial number. The red error border appears to indicate the duplication. Click  to refresh the list of detected serial numbers.

4. Configure every output if needed. Refer to the Actuators section for more detail.
5. Click Save.



SENSOR CONFIGURATION

Auxiliary Lights


Many systems are equipped by auxiliary lights. Lights can be individual or grouped together. In either case, each light must be configured individually.

Light Properties

Serial Number	Defines the light serial number (can be found on a sticker located on the light)
---------------	--

Light Configuration Steps

1. Select the light from System Devices, then click Edit to configure the light.
2. Enter or select from the drop down list the light Serial Number.
3. Click Save
4. Repeat steps for the remaining lights



LIGHT CONFIGURATION

Note: Each device must have a unique serial number. The red error border appears to indicate the duplication. Click to refresh the list of detected serial numbers.

Discrete State Devices (Switches)


There are systems equipped by switches to turn on/off system components. The number of switches and their possible states are predefined by the configuration file.


Switch Properties

Serial Number	Defines the switch serial number (can be found on a sticker located on the switch)
---------------	--

Switch Configuration Steps

1. Select the switch from System Devices, then click Edit to configure the switch.
2. Enter or select from the drop down list the switch Serial Number.
3. Click Save
4. Repeat steps for the remaining switches

Note: Each device must have a unique serial number. The red error border appears to indicate the duplication. Click  to refresh the list of detected serial numbers.




SWITCH CONFIGURATION

Enabling/Disabling Devices

Each device, or any of its subcomponents, may be enabled or disabled. The most common scenario is to prevent a malfunctioning device, or its subcomponent(s), from interfering with communication to other working devices.

Note: Disabling a device will disable all its user interface control elements, but the device will still be visible on the Control Ribbon.

In case of composite devices, disabling any number of subcomponents will cause a warning icon  to appear on the component device control panel tile header. If ICON™ is not enabled to establish a connection with any of the devices or their subcomponents, it disables the faulty devices itself, but errors notifying of these connection failures come up on the screen.



DISABLING THE WHOLE CHASSIS OR AN INDIVIDUAL TRACK

Note: The system communication must be restarted when any device enabled/disabled status has been changed.

Renaming System Components

All devices and channels are given some unique titles used for identifying and referencing them. They are used in the System Configuration Manager, on the Control Ribbon, Control Panel, and Instrument Panel tile headers. The title can be changed, however, if needed.

To rename a device or a channel complete the following steps:

1. Navigate to Backstage -> Configurations.
2. Select a configuration from the configuration list.
3. Select a component from the list of system components.

Click the edit icon to start editing. Enter the desired title. It is recommended to keep it concise and descriptive. When completed click either save or X cancel the changes.




RENAMING A SYSTEM COMPONENT

Reel Encoder

By default, no configuration has a reel encoder. The operator, however, can add the encoder to every configuration or remove it if not needed. To add the encoder to a configuration, complete the following steps:

Navigate to: Backstage -> Configurations.

4. Select the loaded configuration.
5. Select a channel to put the encoder on. It can be either an existing configuration channel or a new channel not presented in it. Click OK to complete the operation.
6. Once being added, the communication will be restarted automatically, and the encoder will appear among the rest of devices. By nature, the encoder is just a sensor. The operator will have to configure it as an ordinary sensor device.



REEL ENCODER CONFIGURATION

To remove the reel encoder, just click "Remove Encoder" icon and confirm the action. Like adding the encoder, the com-

munication will be restarted automatically, the encoder will disappear.

Note: Removing the encoder will result in removing all tiles from Instrument Panel associated with it.

Plugins

Plugins provide the operator with the ability to control third-party sensors and devices that are not developed by Eddyfi Technologies. By installing plugins, the functionality of ICON™ is significantly extended. Refer to a specific plugin manual for more details.

Internally, plugins are library files (*.dll) that must be physically stored on the hard drive. Some plugin library files are already included into the ICON™ installation package. To add a plugin file later, complete the following steps:

7. Acquire a plugin library file(s) from Eddyfi Technologies, according to the third-party device.
8. Navigate to ICON™ installation folder through path: C:\Program Files\ICON 4\.
9. Create a folder under the root of this folder called Plugins, if it doesn't already exist.
10. Open the Plugins folder and then create another folder under this directory to place the library file. The folder name is flexible, but it is easier to manage plugins if this correlates to the third-party device.
11. Copy and paste the *.dll file(s) into the new folder.

Adding plugin Packages

To add a plugin to the system, complete the following steps:

1. Navigate to: Backstage -> plugins.
2. Select the available plugin from the drop down list under the title Available plugin Packages.
3. Click to add the desired plugin.

Added plugins will be displayed in Selected plugins list.

Configuring Plugin Device

Like standard Eddyfi devices, plugin devices require configuration before using. The configuration process is the same most time. Normally, a plugin requires the following configuration steps:

1. Select a plugin from the Selected Plugins list.
2. Set the communication channel for the device, choosing the appropriate port.
3. Set available running parameters for the device if any.
4. Enable or disable a plugin device by clicking the toggle button beside its name in the Selected Plugins list.

Removing Plugin Device

To remove a plugin, select a plugin from the Selected Plugins list. Click delete beside its name and confirm the action.

Note: Removing the plugin will result in removing all tiles from Control Panel and Instrument Panel associated with it.


Calibration

Generally, calibration is an operation to establish a relationship between an actuator or sensor feedback value and some value measured usually manually by an instrument. There are many calibration types in ICON™ software. In some cases, it affects the precision of a feedback value; in others, it defines the operational parameters of a device. All feedback parameters are split into two categories: those to be calibrated on the Backstage, and those to be calibrated on the

Control Ribbon. By default, devices come pre-calibrated from the factory. Backstage calibration is used for feedback parameters which must be re-calibrated only under some exceptional circumstances. Control ribbon calibration, by contrast, is used for feedback parameters whose recalibration is a part of routine operations.

Calibration Manager

The Calibration Manager is used to calibrate the operational parameters of a device. It shows only devices that have feedback parameters to be calibrated on the Backstage. ICON™ Calibration Manager will provide some guidance as to which feedback parameters remaining are not calibrated, by highlighting them with a red box. It also highlights all devices with at least one feedback not calibrated.



CALIBRATION MANAGER


Calibrating Device Feedback

Calibration process varies for different feedback parameters. For convenience, ICON™ Calibration Manager will lead through the process by providing some guidance.


To calibrate a device feedback parameter on the Backstage, complete the following steps:

5. Navigate to: Backstage -> Calibration.
6. Under the System Devices column, select the device to be calibrated.
7. Select the device feedback from the list in the Device Feedbacks column.
8. Click Calibrate in the upper right corner.
9. Follow the calibration steps to calibrate the feedback.

Note: If the feedback is already calibrated, the Reset button is shown instead. Click it to drop the feedback calibration, confirm the action, then proceed.



BACKSTAGE CALIBRATION PROCESS SAMPLE



CONTROL RIBBON CALIBRATION PROCESS SAMPLES

Task Automation

Automation is the ICON™ software utility that allows the operator to automatically monitor the system parameters or/and perform tedious and repetitive tasks. All automation units are split into two categories: automation rules and routines. A rule defines a condition and action that is performed when the condition is met. A routine defines a sequence of steps the system must perform without the operator interaction.

Based on this division, ICON™ software has Automation Rules Manager and Automation Routine Manager respectively. Both allow the operator to import and configure automation rules/routines. To import an automation rule/routine, navigate to Backstage -> Automation -> Automation Rules / Automation Routines, and click the Import button.

The next steps are like importing system configurations. Refer to the Getting Started -> Importing Inspection System Configuration(s) section for more detail.

Automation Actions

All automation actions that can be executed fall into the following distinct Action Type Categories:

Alarm Action – When triggered, this action displays an alarm to the operator on the main control screen. When designing the rule, the designer will need to specify whether the user will be required to acknowledge the alarm or not and, also, to define the severity of the alarm.


Crawler Action – When triggered, this action provides a specific command to the crawler, a communication channel, or to a specific device.

Job Action – When triggered, this action allows changes to Job status and Job attributes.

Video Action – When triggered, this action allows Video recording, snapshots, Tags, Annotations, and Camera-to-display mapping changes.

Automation Variables


Some actions require additional arguments to start execution. The values of arguments can be either hard coded by the action's designer or bound to variables. ICON™ software allows the operator to change the value of variables and, thus, change the behavior of an action.



AUTOMATION VARIABLES

Both automation rules and routines have the same automation variable management. To change a rule/routine variable values, complete the following steps:

1. Navigate to: Backstage -> Automation -> Automation Rules / Automation Routines.
2. Select the rule / routine.
3. Click Edit.
4. Set desired values
5. Save




EDITING AUTOMATION VARIABLE VALUES

Note: the check box on the right side of a variable title is for routines only. They define whether the operator can enter another value for this variable when a routine starts, or the value defined as described above will be used always.

Automation Rules

Automation rules are specific actions that are executed when a predefined condition is met. Actions can be set for conditions based on the sensor values for devices, as defined by the configuration. Parameters such as current draw, input voltage, encoder counts, speed, pitch, tilt, roll, temperature, and humidity values are just a few examples.

The most common scenario is to use an alarm action to indicate some extreme conditions or failures. In this case, alarms will be seen on the Alarm Panel right below the Control Ribbon, and/or on the Alarm section of the Event Panel on the right side. Automation rules come into effect immediately after being imported. The operator, however, can enable/disable if required.



ENABLING AUTOMATION RULES

Automation Routines

Automation routines allow a custom implementation for conditional and looping expressions to control an inspection system autonomously.

Actions can be set for conditions based on the sensor values for devices, as defined by the configuration. Parameters such as current draw, input voltage, encoder counts, speed, pitch, tilt, roll, temperature and humidity values are just a few examples.

Automation routine execution is controlled on the Automation Viewer which can be toggled by clicking on the Automation Viewer Button




TOGGLING THE AUTOMATION VIEWER

Note: The expanded viewer occupies a noticeable part of a display. Some low-resolution displays can have no more room to accommodate the Instrument Panel after this. An appropriate notification will be shown in this case.

To select and run a routine, complete the following steps:

1. Expand the Automation Viewer.
2. Select the routine to run from the drop down list.
3. Click Start



AUTOMATION ROUTINE VIEWER

Note: If the desired routine has variables with its value allowed to change when the routine starts, an appropriate dialog will prompt the operator to either confirm or enter the values

4. Stop or Pause the running routine if needed.
5. Resume the routine if paused.
6. Once the routine is completed, it stops automatically.
7. Note: If any routine is running and the operator is leaving the main Control and Operation Screen, the routine will be paused automatically. The operator must resume the routine manually to proceed.

Note: Automation functionality is under constant development and, therefore, can differ from described above. Some

systems are equipped with the Automation Routine / Rule Designer. It is recommended consulting with Eddyfi Technologies qualified personnel for instructions on how to use it first.

Settings

Settings contains all the ICON™ software system features that can be created and edited depending on system configuration and desired operational functionality. Features in System Manager include:

- Job Attributes
- Inspection Standards
- Gamepad Profiles
- Instrument Panels
- Control Panels
- Default Overlay
- Preferences

Many of these features can have multiple instances, allowing multiple operators to configure the control system to their liking. For example, multiple Gamepad Profiles, multiple Control Panel layouts, and multiple Instrument Panel layouts are possible.

Job Attributes

Job Attributes are a series of key words and assigned values which help to describe a Job. This metadata is helpful for tracking important information associated with a Job. Location, time, operator, and weather conditions are just a few examples of Job Attributes that can be added.


A Job Attribute allows the operator to specify the pertinent information such as location, Job site, or operator. The Job Attribute Value is an option that the operator starting a Job may select to fill in for each Job Attribute. For example, for a Job Attribute such as a Job site, some attribute values might be “Site A”, “Site B”, “Site C”, etc.

When an operator starts a Job, they will be provided with a dialog box prompting them to enter values for each attribute, using a dropdown menu.

Creating Job Attributes

To create a new Job Attribute, complete the following steps:


1. Navigate to: Backstage -> Settings -> Job Attributes.
2. Click + New Job Attribute, then enter Attribute Title.
3. Select whether the operator can enter the attribute runtime values if required or just select a value from the dropdown list.
4. Select whether the value must be entered before the operator can proceed.
5. Click Save.
6. Click New Attribute Value, then enter an attribute value, select Save.
7. Repeat to create more attributes and their values as desired.



JOB ATTRIBUTE MANAGER

Assigning Job Attributes

Toggle the desired attributes to ON/OFF in the Job Attribute Manager to make Job Attributes visible/invisible in the Start Job dialog box. Select the desired value for every attribute. If an attribute marked as required, the value is mandatory. If an attribute allows runtime values, in addition to selecting values from the drop down list, the operator can edit existing or add new values.




ASSIGNING JOB ATTRIBUTES TO A JOB

Creating External Job Attributes

Job Attribute can also be created from an external source file like *.txt or *.csv. To create a new Job Attribute file, complete the following steps:

1. Open a new file in WordPad.
2. In a new line, write the Attribute Title.
3. Separate with a comma, and then write the Attribute Value.
4. Start a new line and repeat the process.

Note: Attribute pairs that share the title will be categorized into the same Job Attribute Title. Files with .csv use the same format.



CREATING A JOB ATTRIBUTE FILE

Using Job Attributes From An External File

When using an external Job Attribute file, the system settings will need to be changed. To do so, complete the following steps:

1. Navigate to Backstage -> Settings -> Preferences.
2. Click Edit.
3. Navigate to the Job Attributes section.
4. Select Set Job Attribute Source option to Get Attributes from External File.
5. Move to Set Default Job Attribute File Path.
6. Click Open and select the external source file (.txt or .csv).
7. Click Save.

Note: Job Attributes and their values will be replaced by the values from the external file until you set the option back to Get Attributes from Database. No runtime values are allowed.


Inspection Standards Manager

When a user is inserting a tag during a video recording, they can also enter an inspection code with the tag. The code helps users to categorize the problem encountered at the moment when the tag is inserted. The inspection code must be predefined in an inspection code standard. In the Inspection Standard Manager, users can create and manage inspection code. Only one set of Inspection Standards can be used at a time.

Creating Specifications Standards

To create an inspection standard, complete the following steps:

1. Navigate to Backstage -> Settings -> Inspection Standards.
2. Click + New Inspection Standard.
3. Fill in the Inspection Standard Title and Description.
4. Click Save.
5. Click + New Standard Code, then enter the inspection code and its description, click Save.
6. Repeat to create more inspection standards and their codes as desired




INSPECTION STANDARD MANAGER

Setting a Default Inspection Standard

Only one standard can be active at any given time. Click the check box to the left of the standard to select it as the default.

Gamepad Profile Manager

The Gamepad Profile Manager is used to create and edit gamepad profiles and key mapping. Multiple profiles can be created for various users or user groups.




GAMEPAD PROFILE MANAGER

Creating A New Gamepad Profile

To create a new gamepad profile, complete the following steps:


1. Navigate to Backstage -> Settings -> Gamepad Profiles.
2. Click New Gamepad Profile.
3. Enter the Profile Title and Profile Description.
4. Click Save.
5. To map the keys of the created profile, click Edit under Key Mappings.
6. Map keys as desired; refer to the Mapping Gamepad Keys section in this manual.
7. Click Save

Note: Leave the function as No Action to make the key unused.

Note: New gamepad profiles can also be based on existing profiles by clicking on  button to make a copy, and then editing the new profile.

Instrument Panel Manager

The Instrument Panel displays device parameter readings from the system on the main Control and Operation Screen. Parameters such as temperature, input voltage, track speed, and camera tilt can be monitored on the Instrument Panel. The Instrument Panel is made up of two Panel sections – the Regular Panel and the Expanded Panel. The Regular Panel is always displayed on the main control screen, while the Expanded Panel can be expanded or collapsed. Creating and managing Instrument Panels is performed through the Instrument Panel Manager in the backstage.




INSTRUMENT PANEL

Creating A New Instrument Panel

A configuration can have as many instrument panels as needed. To create a new Instrument Panel, complete the following steps:

1. Navigate to Backstage -> Settings -> Instrument Panel.
2. Click “+ New Instrument Panel”
3. Once the new panel appears, design the panel as described below.
4. Click Save.

Note: New instrument panel can also be based on existing panel by clicking on the copy icon to make a copy, and then editing the new panel.



INSTRUMENT PANEL MANAGER

Editing An Instrument Panel

After a new instrument panel has been created, it is already in the edit mode. To edit an existing panel, click Edit under Panel Tiles. To build the panel, panel tiles are dragged and dropped from the Tile Palette. The upper area holds the extended size tiles, while the lower one is the regular size panels. Tiles can be relocated anytime as desired. To remove a tile, drop it over the Tile Palette header highlighted in red.



ADDING AND RELOCATING PANEL TILES

Changing The Size Of A Tile


The tiles are set to their default size when they are initially placed. To change the size, select a tile and click on the arrow in the lower right corner and drag the tile to the desired size.



TILE RESIZING

Changing The Colour Of The Tile

Tile element colours including Foreground, Scale Background, and Scale Accent can be changed. Foreground refers to the displayed measurement value on the scale. Scale Background refers to the open space above or beside the scale. Scale Accent refers to the colour of the scale itself.



TILE COLOUR SELECTION

To change the colors, right click on the tile and select the element to be changed, and then select the desired colour.

Binding Device Parameter To The Tile

To display a desired parameter on the screen, bind the parameter with a properly configured tile. To bind a device parameter to a tile, complete the following steps:

1. Select the tile to be bound to a parameter.
2. Select the desired Device from the dropdown menu.
3. Choose the parameter to bind to the tile from the Parameter dropdown menu.
4. Select a unit for the parameter from the Unit dropdown menu.
5. Repeat for other tiles as required.




BINDING A DEVICE TO A PARAMETER TILE

Note: *A tile with no device parameter assigned is invalid. The panel cannot be saved as long as it has any invalid tiles. Invalid tiles are highlighted in red.*

Setting The Measurement Range For The Parameter


For Horizontal Gauges, Vertical Gauges, Radio Gauges, and Live Charts, displayed ranges can be set to properly show the measured values. There are two ways to set the measurement range: make it either a static or a dynamic. A static range never changes, whereas a dynamic one always adjusts its maximum/minimum values once the actual value exceeds them. By default, the range is dynamic.

To set a static range for a parameter, set Dynamic Range to OFF and enter its Minimum and Maximum values.



SETTING MEASUREMENT RANGE

To set a dynamic range for a parameter, just set Dynamic Range back to ON. For Live Charts, the Duration defines the amount of time the data samples are displayed on the chart. The longer the Duration, the more samples will be displayed. By default, the Duration is 20 seconds, but it can be increased up to 10 minutes.



SETTING SAMPLE DURATION

Setting A Default Instrument Panel


Only one instrument panel can be active at any given time. Click the checkbox to the left of the panel to select it as the default


Control Panel Manager

The Control Panel allows the operator to control multiple system devices on the main Control and Operation Screen. Unlike instrument panels, the system must have at least one control panel which is generated automatically for every system configuration added to the system. A control panel has fixed number of tiles for every device must be controlled. Creating and managing Instrument Panels is performed through the Instrument Panel Manager in the Backstage. The process is like creating and editing Instrument Panels.


Creating A New Control Panel

A configuration can have as many control panels as needed. To create a new Control Panel, complete the following steps:

1. Navigate to Backstage -> Settings -> Control Panel.
2. Click 
3. Once the new panel appears, design the panel as described below.
4. Click Save.



CONTROL PANEL MANAGER

Note: New instrument panel can also be based on existing panel by clicking on button  to make a copy, and then editing the new panel.

Editing A Control Panel

After a new instrument panel has been created, it is already in the edit mode. To edit an existing panel, click Edit under Panel Tiles. Unlike Instrument Panel, control panel tiles cannot be added or removed but can be relocated anytime as desired.

Note: Changing the layout of control panel elements may decrease the size of the main camera display area. If the camera's display area is too small, the instrument panel will not be fully displayed. Undocking the camera display area to a second screen can be utilized to enable larger control panel elements, along with more instrument panel elements.



TILE RESIZING

Changing The Size Of The Tile

The tiles are set to their default size when they are initially placed. To change the size, select a tile and click on the arrow in the lower right corner and drag the tile to the desired size.

TRANSFORMING THE TILE

The tiles are set to their default template when they are initially placed. Some have additional templates available. To transform the tile, right click on the tile and select an available option from the dropdown menu.



TILE TRANSFORMATION

Note: Some templates can take more space than others. If the desired template is shown as an option but disabled, try to clear the space around it.


Overlay Template Designer


The ICON™ software has a built-in Overlay Template Designer, which allows annotation elements to be placed over an exported video.

Creating A New Overlay Template

To create a new Overlay Template, complete the following steps:

1. Navigate to Backstage -> Settings -> Overlay Templates.
2. Click new template Icon
3. Once the new template appears, design the template as described below.
4. Click Save.


Note: New overlay template can also be based on an existing template by clicking  on button to make a copy, and then editing the new panel.



OVERLAY TEMPLATE MANAGER

Editing An Overlay Template

After a new template has been created, it is already in the edit mode. To edit an existing template, click Edit under Template Annotations. To build the templates, annotations are dragged and dropped from the Tile Palette. To remove an annotation, drop it over the Tile Palette header highlighted in red.



ADDING AND RELOCATING ANNOTATIONS

Changing The Size Of The Annotation

The annotations are set to their default size when they are initially placed. To change the size, select an annotation, move the mouse cursor to its any edge, and drag the annotation to the desired size.

Annotation Types


There are five annotation types currently supported by the ICON™ software; grouped into three categories:

- Text annotations (allows to enter any text, multiple sensor values in the form of text, and metadata values such as date and time as well as job and video titles)
- Image annotations (allows to display a single image)
- Gauge annotations (allows to display a single sensor value in the form of a horizontal, vertical, or radial gauge)

To edit an annotation of any type, select it and its property editor will slide up. Property editors vary for different annotation types.

Setting Text And Annotation Properties


For text annotations, it is possible to select colours including Background and Foreground and their opacity. The foreground colour is also applied to the annotation border. The border thickness can also be adjusted. Some text properties including a font size and family as well as text horizontal and vertical alignments are also available



TEXT PROPERTY ANNOTATIONS


The user can type any random text and/or bind the text with either a sensor or metadata values. To display a desired sensor on the annotation, they must be first bound together. A text annotation can be bound with multiple sensors. To bind a sensor to annotation, complete the following steps:

1. Select the annotation to be bound to a sensor.
2. Put the cursor at the desired position in the text
3. Click Add Sensor button. The dialog box will pop up.
4. Select the desired Device from the dropdown menu.
5. Choose the parameter to bind to the tile from the Parameter dropdown menu.
6. Select a unit for the parameter from the Unit dropdown menu.
7. Click OK.



BINDING A SENSOR TO AN ANNOTATION


In the text, sensors are represented in the encoded format like @[Device].[Sensor].[Unit]. It is not recommended to modify sensor definitions manually.



TEXT ANNOTATION SENSOR BINDING SAMPLE

To bind a metadata to annotation, complete the following steps:

1. Select the annotation to be bound to a sensor.
2. Put the cursor at the desired position in the text.
3. Click Add Metadata button. The dialog box will pop up.
4. Select the desired Metadata type from the dropdown menu.
5. Click OK.



BINDING A METADATA TO AN ANNOTATION

In the text, metadata are represented in the encoded format like @[Metadata]. It is not recommended to modify metadata definitions manually.

Setting Image Annotations Properties

Like text annotations, for image ones, it is possible to select colours including Background and Foreground and their opacity. The foreground colour is applied to the annotation border. The border thickness and the image opacity can also be adjusted.




IMAGE ANNOTATION PROPERTIES

To add an image to the annotation, click Load Image and select a desired image file. *.jpg, *.bmp, and *.png files are supported. Big image files will be automatically resized to the maximum image annotation size of 400 x 400 pixels.

Setting Gauge Annotation Properties

For Horizontal Gauges, Vertical Gauges, and Radial Gauges, it is possible to select colours including Background, Foreground, Accent and their opacity. The border thickness can also be adjusted. Unlike text annotations, a gauge can be bound with one sensor only.



GAUGE ANNOTATION PROPERTIES

For every gauge, its displayed range can be set in order to properly show the measured values. There are two ways to set the measurement range: make it either a static or a dynamic. A static range never changes, whereas a dynamic one always adjusts its maximum/minimum values once the actual value exceeds them.

By default, the range is dynamic. To set a static range for a parameter, uncheck Dynamic Range and enter its Minimum and Maximum values. To set a dynamic range for a parameter, just check Dynamic Range.

Preferences

The ICON™ software supports global preferences applied to the whole system and all users, including administrators, regardless of group identity.

User Interaction Group

- Leaving Control Screen Confirmation – Enables a confirmation prior to leaving the Device Control.

Device Control Group

- Pan Inversion – Inverts the pan direction of the camera.
- Tilt Inversion – Inverts the tilt direction of the camera.
- Pan/Tilt Scaling – Enables scaling of the camera Pan & Tilt speed with the current.

Gamepad Controller Group

- Gamepad Enabled – Sets whether a gamepad can be used to control the system.
- Left Stick Dead Zone Shape – Sets the dead-zone shape of the left joystick.
- Left Stick Dead Zone Size – Sets the dead-zone sensitivity of the left joystick.
- Right Stick Dead Zone Shape – Sets the dead-zone shape of the right joystick.
- Right Stick Dead Zone Size – Sets the dead-zone sensitivity of the right joystick.

System Notifications Group

- Error Logging Level – Defines the level of system error and specific notifications which will be logged to the database. Available levels are: Low (All Possible Errors), Medium (Medium and High Severity Errors Only), and High (High Severity Errors Only).
- Error Notification Level – Defines the level of system error and specific notifications which will be pop up on the screen. Available levels are: Low (All Possible Errors), Medium (Medium and High Severity Errors Only), and High (High Severity Errors Only).

Export Group

- Automatic Snapshot Export – Controls whether Snapshots are automatically added to the export queue when a recording or Job is stopped.
- Automatic Video Export – Controls whether Videos are automatically added to the export queue when a recording or Job is stopped.
- Default Export Location – Controls where videos and snapshots from ICON™ are exported.
- Default Export Mode – Sets the default mode for video export operations. Available modes are Original Video, Formatted Video, Template Annotations.
- Default Video Export Format – Sets the default video format. It is applied only if Formatted Video export mode is selected. Available formats are Same as Source, NTSC, PAL, 1080i 59.94 fps, 1080i 30.00 fps.
- Default Video Export Quality – Sets the default video export quality (the higher the percentage, the higher output bitrate and more disk space required)
- Default Video Overlay Template – Sets the default video overlay template which will be applied when the Template Annotations export mode is selected.

Job Attributes Group

- Job Attribute File – Sets the path of the external file from which to import Job Attributes.
- Job Attribute Source – Sets the source from where ICON™ gets Job Attributes; it can either get the Job Attributes from the database or from external files.

Data Group


- Log Debug Parameters – When enabled, ICON will log additional device data for diagnostic purposes. Enabling this preference will cause ICON to use additional database space.
- Value Change Threshold – Defines the amount a data value must change before it is updated in the database. Increasing this value will reduce ICON's database usage but decrease the accuracy of data. At 0%, ICON will log all value changes.

About

In the About section, operators can find information about ICON™ and its activation status, as well as access the user manual. ICON™ Software Licensing and Elevated Permissions are also managed in this section.

Application Info

Application Info displays ICON™ Software application information such as Release and Build.



Application Info	
Company	Eddyfi Technologies www.eddyfitechnologies.com/
Application	ICON™
Release	4.8
Build	4.8R1T3

APPLICATION INFO

License Status

ICON™ software requires a license for each computer it is installed on. License Status provides the current license status information as well as information about the contact person.

Licensing Models

There are two licensing models provided by Eddyfi Technologies - perpetual and subscription-based. Despite remaining subject to change, the former is paid up-front and provides the 5-year coverage; whereas the latter is priced on a yearly basis and provides the 1-year coverage. Contact the Eddyfi sales team for more detail.

Activation Modes

There are two activation modes available - on-line and off-line. It is recommended to select the on-line activation mode for all computers that have permanent or periodic access to the Internet and select the off-line mode only for computers that have no Internet access at all. Both the perpetual and subscription- based licenses can be activated in either way – on-line or off-line. *Note: Off-line activation is available only when the computer has no Internet access.*

Refresh Time

ICON™ software requires the license status to be periodically verified and updated. By default, the refresh intervals are one day for online licenses and one year for off-line licenses. To keep operating normally, the computer must be connected to the Internet at least once within this period.


License Release

The number of the computers that can be activated with the same license code is determined by the license. ICON™ software will reject attempts to exceed this limit. In case of a need to replace a computer and/or move a license to another one, the previous license activation must be released first.

Current License Information

The specific license information available to a customer are determined by the software license. Typically, it includes:

- Licensing system connection status
- License status
- License code
- Computer ID
- License type
- Last refresh time
- Subscription expiration date
- Maintenance expiration date
- Next required refresh time



LICENSING STATUS CONTACT INFORMATION

Please refer to 'ICON – Nalpeiron Desktop License Activation & Software Updates' manual for more detail about licensing management.

License Agreement

In this section, operators can review the License Agreement, which has been acknowledged when installing ICON™ Software Suite.

Manuals

In the Manuals section, operators can view the ICON™ C User Manual (this manual) for operating instructions.


Elevated Permissions

In this section, an operator may temporarily elevate permissions of his or her user group to access all the available features defined by the main license.

To activate the license off-line, complete the following steps:

1. Navigate to Backstage -> About -> Elevated Permissions.
2. Click the Save As button to temporarily save the Installation Key file (*.iink).


3. Email the installation key file to [license.icon@eddyfi.com/](mailto:license.icon@eddyfi.com)



SAVING THE INSTALLATION KEY

Note: The activation process may take 1-2 business days for a response

4. After the elevated permissions request is received and processed, an Offline Activation Response file (.iepk) will be returned. Click the Activate button and navigate to the location of the provided activation key.
5. When the import dialog pops up, select the licensing code file (*.iepk) and then select a computer to be activated. Click the Ok button to complete the selection.



SELECTING ELEVATED PERMISSIONS KEY

1. Click the OK button. The ICON™ software elevated permissions is now activated.
2. The elevated permissions will be automatically deactivated upon expiration. To deactivate them manually, click the Deactivate button.

Control and Operation

All devices supported by ICON™ software are split into the following categories:

- Cameras
- Navigation
- Auxiliary Lights
- Actuators
- Sensors

To select a device for control, use one of the following options:

- Select the appropriate tab on the Control Ribbon, then select the device to be controlled.
- Alternatively, select a tile on the Control Panel, ICON™ software will select the right tab and device on the Control

Ribbon automatically.

- Use the keyboard to switch between devices. Refer to the Keyboard Control section for more details.



SELECTING A DEVICE FOR CONTROL

The selected device will have a brown border on the Control Ribbon and, if it has a Control Panel tile, a blue border will appear around the tile.


Camera Control

Eddyfi Technologies systems can be equipped with multiple cameras. Some of them are designed for capturing video and cannot be directly controlled through ICON™ software. They are, however, still visible on the Camera tab of the Control Ribbon and the Device Manager but have no correspondent tile on the Control Panel. Available camera control options vary based on the specific camera type.

Video Switching


ICON™ software supports up to two displays: the primary and the secondary ones. It causes the camera selector to have two level of selection correspondingly. The primary selected camera will have a yellow border on the Control Ribbon and the selected secondary camera will have a blue one.

The video stream coming out of the primary camera is always shown on the primary display, coming out of the secondary camera – on the secondary display. Refer to the Picture-In-Picture section below for more details.



PRIMARY & SECONDARY CAMERAS

Note: If a system is equipped with more than two cameras, a video switching device will be required. The mapping algorithm and the number of possible switching permutations can vary based on the specific system configuration. The operator cannot switch cameras, however, if both cameras currently mapped to displays are recording.



ZOOM CONTROL

Camera Imager Control ZOOM

If a camera has Zoom, its control is located on the left of the camera controller, on the Control Panel tile, outlined below in red. Moving the slider up and down will enable the camera to zoom in and out.

The slider position controls the rate of the cameras' zoom and, therefore, will zoom faster as the slider moves further away from the center point. Releasing the slider will automatically stop the camera zoom.

The zoom in and out buttons (magnifying glasses) at the top and bottom of the zoom slider can be used for the maximum speed zoom adjustment.

Focus

If a camera has focus, its control is located on the Control Ribbon. By default, Focus is initialized to Auto. Select Manual to manually focus the camera. The +/- icons can then be used to focus IN and OUT.

Note: When switching from manual to auto focus, the camera may not immediately focus. In this case, zoom IN or OUT to trigger the camera's auto focus.

FOCUS CONTROL



Auto Focus Sensitivity

If a camera has Auto Focus Sensitivity, its control is located on the Control Ribbon. It defines how fast the camera adjusts its focus and is only available if Auto focus is selected. By default, Auto Focus Sensitivity is set to Low. Select High if a more immediate focus response is required.




AUTO FOCUS SENSITIVITY

Exposure




EXPOSURE CONTROL

If a camera has Exposure, its control is located on the Control Ribbon. Generally, it defines the brightness of the video. By default, Exposure is initialized to Auto. Select Manual to enable the Manual Exposure  adjustment. The buttons can then be used to adjust the Exposure levels. Hold the buttons down for faster exposure response.

Camera Light Control

On Spectrum 90™, Spectrum 120™, and MaggHD™ cameras, the lights can be individually controlled. Individual lights can be toggled ON and OFF on the Control Ribbon, while Brightness is controlled at the Camera Device control tile on the Control Panel.



LIGHT INTENSITY CONTROL

To control lights individually, toggle the Lights control button to turn specific lights ON or OFF. To adjust the light intensity, use the slider bar located to the right of the camera controller, outlined here in red.



INDIVIDUAL LIGHT CONTROL

Click any position on the slider bar to reach an intensity level directly. The max and min light buttons at the top and bottom of the zoom slider can be used for setting the light intensity to the minimum and maximum level respectively.

Laser

If a camera has Lasers, its control is located on the Control Ribbon. Toggle the button to turn lasers ON or OFF.



LASER

Defog/Lowlight

If a camera has Defog/Lowlight, their controls are located on the Control Ribbon. The Defog Mode reduces the effects of the fog and make objects appear clearer. The Low Light reduces the noise in low-illumination conditions. By default, both Defog and Low Light are initialized to OFF. Toggle these buttons to enable the Defog or Low Light features.



DEFOG/LOWLIGHT

Stabilization

If a camera has Stabilizer, its control is located on the Control Ribbon. The Stabilizer Mode reduces image blurring cause by, for example, vibration. By default, this feature is initialized to OFF. Toggle the button to enable image stabilization.

Note: When Stabilizer is toggled ON via the Video Panel, a blue screen will appear momentarily and recover automatically. This is normal.



STABILIZATION


If a camera has Stabilizer, its control is located on the Control Ribbon. The Stabilizer Mode reduces image blurring cause by, for example, vibration. By default, this feature is initialized to OFF. Toggle the button to enable image stabilization.

Note: When Stabilizer is toggled ON via the Video Panel, a blue screen will appear momentarily and recover automatically. This is normal.

Picture-In-Picture


If your Eddyfi Technologies system is equipped with two or more cameras, (Picture-in-Picture) control is available and located on the Control Ribbon.

When toggled to ON, the secondary display will appear on the Video Panel, so video signals from two cameras can be observed simultaneously. Refer to the Video Switching section above for more details.



PIP CONTROL

The secondary display can be placed at any location on the Video Panel. By default, it is docked in the right bottom corner. The four corner buttons on the Control Ribbon can also be utilized to dock the display around. For more precise positioning, the display can be dragged and dropped.



MULTI-CAMERA DISPLAY

Crosshair


When the Crosshair mode is enabled, right-angled bisecting lines will appear on the video panel. Crosshair can be used to determine the screen centre or as reference when observing objects and estimating sizes or features of interest.

Camera Attitude Control (Pan/Tilt)

The attitude of a camera consists of two functions, Pan and Tilt. Spectrum™ cameras have both elements while the MaggHD™ is Tilt only. The attitude of a camera can be manipulated to target an object for observation.

Functions to manipulate a camera are:

- Move the virtual joystick Up to tilt upward.
- Move the virtual joystick Down to tilt downward.
- Move the virtual joystick Left to pan Left.
- Move the virtual joystick Right to pan Right.
- Move the virtual joystick Diagonally to pan and tilt in an arbitrary direction.



CAMERA VIRTUAL JOYSTICK

Note: The virtual joystick can also be locked in position for continuous pan and tilt, without the operator having to hold the joystick in position. To lock the joystick, use keyboard control. Refer to the Keyboard Control section for details.

Camera Set Points



SET POINT SETTING

For cameras with Pan/Tilt control, the Set Points option is available. It allows the operator to store camera current pan/tilt positions (set points) in memory and return to them as required.

By default, the only stored set point is the Home with pan and tilt values equal zero.


To move to a set point, click Set Point on the camera controller, select Existing option on the popup menu, select a desired set point.

To create a Set Point, navigate the camera to the desired position, click Set Point on the camera controller, select New option on the popup menu, enter in the title, click Save.

Track Control

Eddyfi Technologies systems can have multiple tracks for locomotion. From the control perspective, they are all grouped into a single unit called a Chassis. Through ICON™ software, the operator can control a chassis but not a single track. All chassis are visible on the Navigation tab of the Control Ribbon and the Device Manager and have correspondent tiles on the Control Panel. Control Modes


Control Modes



CHASSIS CONTROL MODES

All Eddyfi Technologies tracks have two control modes, Speed and Power. To change between the two, open the Navigation tab of the Control Ribbon, select the chassis; then click on either button on the Control Mode group. Speed control will actively maintain the set track speed adjusting the power, while Power control simply keeps the power at some level so the speed can vary based on the load. Both control types allow the operator to control the direction and speed of a vehicle.

Moving & Steering



TRACK CONTROL

To move a vehicle forward or backward, adjust the vertical slider upward or downward. To control the moving direction of the vehicle, the middle position of the vertical slider means zero throttle. Use this function in conjunction with turning to make gentle sweeping turns with the vehicle.

Note: Being released, the throttle slider retains its value, and the system keeps moving. In case of emergency, refer to the Emergency Stop section below to stop the system instantly.


To turn a vehicle, adjust the horizontal slider to the left or right, to control the turning direction of the vehicle.


The chassis can be steered in two different modes: in Crawler Steer mode, there is no need to apply throttle to turn; the system can pirouette in place by moving only the horizontal slider, as one track will move forward and the other will move backward. In Throttle Steer mode, the crawler cannot turn without moving forward or backward. By default, the Crawler Steer mode is enabled.

Refer to the User Groups -> Group Preferences section to set the steering mode preference.

The Chassis Control has power/speedometer displays placed on either side of the control. These displays are linked to the very left and right front tracks (depends on the direction) and are indicative of the power/speed percentage. Green color indicates that the track on that side intends to move forward, and red color indicates that it intends to move backward.

Emergency Stop

When the tracks are set to Speed control, selecting  on the Chassis Control sets the speed of all tracks to zero. Tracks will servo to the zero position and will resist movement if there is a force trying to push them; for instance, a magnetic crawler on a vertical wall will hold position.

When the tracks are set to Power control, selecting  on the Chassis Control sets the power of all tracks to zero. Tracks will be free to back-drive; for instance, a magnetic crawler on a vertical wall will begin rolling down.

Track Reversal

Tracks are physically all identical – there is no difference between a right track and left track. By installing a track on the right side, only its orientation is reversed. In order to have it move in the direction consistent with its controls, the right track must be set to Reversed. Go to Device Manager and find the subsection for Right Track in System Device section, then set Is reversed option to ON.

Note: Changing this setting to OFF for right tracks or changing this setting to ON for left tracks is not recommended.



DEVICE MANAGER-IS REVERSED

Actuator Control


Eddyfi Technologies systems can be equipped with different actuators. All actuators are visible on the Actuators tab of the Control Ribbon and the Device Manager and have correspondent tiles on the Control Panel.

Actuator Control Modes

Eddyfi Technologies actuators have three operational modes:

- **Power** – allows to adjust the actuator power.
- **Speed** – allows to maintain the actuator set speed.
- **Position** – allows the actuator to move to the specific position.

From the control perspective, an actuator can work in one of two modes, Manual and Auto. To change between the two, open the Actuators tab of the Control Ribbon, select the actuator; then click on either button on the Control Mode group.



ACTUATOR CONTROL MODES

The Manual control mode is always the Power operational mode and it is supported by all actuators. The Auto control mode depends on the actuator type and varies. Both control modes allow the operator to control the actuator.


Note: In case if an actuator only supports the Power operational mode, the Auto control mode coincides with the Manual mode, and the Control Mode selector is hidden.

By default, actuators work in the Auto mode. The Manual mode is used to keep control under actuator in case of emergency when the normal control is unavailable due to, for example, broken speed/position encoders.

Operating in the Manual mode results in changing an actuator's behavior. Thus, the warning icon will be shown on the Control Ribbon.

Power Control


To control the actuator power, drag the slider knob away from the centre into the desired direction. The further the knob from the centre, the faster the actuator moves. The knob does not hold its position. To stop the actuator, just release the knob.



POWER CONTROL

Speed Control


To control the actuator speed, set the desired speed first using the slider. The knob holds its position. To move the actuator, click and hold one of the buttons below the slider. To stop the actuator, just release the button.




SPEED CONTROL

Position Control

The slider on this control represents the actuator motion range as it is defined by calibration. To control the actuator position, drag the slider knob to the desired point within the range. The green bar shows the actual actuator position. It can be used to monitor the actuator movement when direct observation is impossible.

To stop the actuator, click on  button. For actuators with position control, the Set Points option is available. It operates like camera Set Points do. Refer to the Camera Control -> Camera Set Points section for more details.



POSITION CONTROL

Push Button Control

For most actuators, the Push Button Control option is available. Based on the actuator operational mode, clicking on either button will result in the following behaviour:

- **Power** – moves the actuator with maximum power in the desired direction.
- **Speed** – moves the actuator at maximum speed in the desired direction.
- **Position** – moves the actuator toward the maximum or the minimum position within the actuator motion range.

The option can be achieved by changing the actuator control template.




PUSH BUTTON CONTROL

Refer to the Settings -> Control Panel Manager -> Transforming the Tile for more details.

To to reverse the control relationship between arrow keys and rotation directions, complete the following steps:

1. Navigate to Backstage -> Devices.
2. Select the actuator in the System Devices list.
3. Click Edit.
4. Toggle it to ON to reverse the rotate direction.
5. Click Save




REVERSE ACTUATOR DIRECTION

Sensor Control

Eddyfi Technologies systems can be equipped with different sensors. All sensors are visible on the Sensors tab of the Control Ribbon and the Device Manager, but none of them have correspondent tiles on the Control Panel.

Some sensors can have calibration sections which can vary based on the sensor type.

Refer to the Calibration -> Calibration Device Feedback section for more detail.



SENSOR CALIBRATION SAMPLE

Switch Control

Eddyfi Technologies systems can be equipped with discrete state devices (switches). All actuators are visible on the Switches tab of the Control Ribbon and the Device Manager and have correspondent tiles on the Control Panel.

Switch States

Eddyfi Technologies switches can be either binary (just two states like ON/OFF) or multi-state with up to 256 different states. In the former case, the control represents a simple button with ON/OFF states. To switch the state just click on the button.



SWITCH ON/OFF BUTTON





MULTI-STATE SWITCH SLIDER

In the case of the multi state switch, the control represents a slider similar to the actuator position control. To control the switch state, drag the slider knob to the desired state within the range. The green bar shows the actual switch state. It can be used to monitor the actual switch state when direct observation is impossible.


Job Management

Starting a Job

A Job is a key term in ICON™ software. A Job instance contains all telemetry data, video, snapshots, tags, etc. To start a Job, click on  button on the Control Panel, and a dialog box will appear, prompting the operator for information about the Job. The number of fields to fill in depends on the number of Video started recording automatically and Job Attributes defined in the system. Refer to the Settings -> Job Attributes and Job Recording -> Video Recording sections for more details.




START JOB DIALOG BOX

Once a Job is started, ICON™ software will automatically start recording all telemetry data which can be retrieved later for analysis and reporting purposes. To stop a Job, click the  button on the Control Panel.

Video Recording







Recording Mode

ICON™ software provides for every camera the Default Recording option. Enabling this option causes cameras currently mapped to either of the displays to start video recording automatically when a Job starts. Coupled with disabling the Job Management -> Enable Video Controls, this leads the system to switch into the Simplified Video Recording mode. It implies a one-to-one relationship between a Job and a Video. By contrast, the Advanced Video Recording mode allows to have multiple Videos within a Job.

In the Advanced Video Recording mode, when a Job is started, cameras with the Default Recording option ON will start recording automatically. Other cameras with the Default Recording option OFF, will not. In this case, the operator must start recording manually by clicking  button on the Job Control Tool Bar. A dialog box will open, prompting for a Video Title. Regardless the Default Recording option, the operator can start and stop video recording at any time without stopping a Job.


Each video within a Job will have a unique identifier even if the operator prefers to keep the same title for all videos. Refer to the ICON™ Backstage Job Control -> System Devices -> Configuring System Devices -> Cameras section for more detail on how to change the Default Recording option for a camera.

In the Simplified Video Recording mode:

1. Click  button to start a Job.
2. Fill out the Start Job dialog box and click OK.
3. All cameras with the Default Recording option ON will start recording immediately.
4. Click  to stop the Job. and stop recording for all cameras. In the Advanced Video Recording mode:
5. Click  button to start a Job.
6. Fill out the Start Job dialog box and click OK.
7. All cameras with the Default Recording option ON will start recording immediately.
8. Click  button on the Job Control Tool Bar of either display to start video recording.
9. Click  button on the Job Control Tool Bar of either display to stop video recording.
10. Create additional Videos within the current Job by repeating steps 4 and 5.
11. Click  to stop the Job. and stop recording for all cameras.

Note: Verify the video recording if system power is interrupted during an inspection. Video files may be corrupt or damaged.





START/STOP RECORDING

Available Free Space Monitor

ICON™ software provides an available free disc space monitor to detect when the data disc drive is full and video recording cannot be carried on any longer. The monitor has a Status Icon located on the System Status Panel. The monitor has three states: Normal, Warning, and Critical.



Normal. If the hard drive has more than 20 GB available free space, the icon is green with its free space indicator full. It is safe to keep video recording at this stage.



Warning. When the available space is less than 20 GB but more than 5 GB, the icon is orange with its free space indicator showing the remaining space. An appropriate notification will pop up. At this stage, it is strongly recommended to stop video recording and any job running; clean up the hard drive by removing all unnecessary files and transferring old jobs to another storage.



Critical. When the available space is less than 5 GB, the icon will turn red with its free space indicator empty. An appropriate notification will pop up. Any job running will be stopped automatically in 30 seconds.

Exporting Videos

ICON™ software provides two modes of video export, Automatic and Manual. Refer to the ICON™ Backstage -> Settings -> Preferences -> Export section to select the default mode and the desired export parameters.

AUTOMATIC VIDEO EXPORT

All the videos will be exported automatically to the default export location automatically whenever the video stop being recorded.

MANUAL VIDEO EXPORT

To manually export video and learn more about Video Export Manager, refer to the ICON™ Backstage -> Export section

Note: ICON™ software requires a Hard Disk Drive with at least 3.0 GB/s to guarantee successful video export. A slow hard drive may block the rapid read and write operation from ICON™ software.

Video Export Agent



Refer to the ICON™ Backstage -> Export section to learn more about the Video Export Manager and the Video Export Agent. The interface of the Video Export Agent shows all the videos that are queuing for export or being exported within the current session. The following information is available for every video:

- Export progress
- Time the video being made
- Duration of the raw video,
- Exported length of the video
- Elapsed and remaining time of export

During the video export process


- click  to cancel the export.

When the export is completed

- click  to play the exported video in the Windows default video player
- click  to open the location of the video in the File Explorer.

If the export of a video gets stuck for an unreasonable time, it is suggested to cancel and reattempt the export. Complete the following steps to do so:

1. Navigate to Backstage->Export.
2. Click the Clear Video Export button to reset the video export statuses.
3. Click the Restart Video Export button to restart the Video Export Agent.



ICON™ VIDEO EXPORT AGENT

Note: ICON™ software requires a Hard Disk Drive with at least 3.0 GB/s to guarantee successful video export. A slow hard drive may block the rapid read and write operation from ICON™.


Taking Snapshots


ICON™ software, snapshots can of two categories: Independent or In-Job. The former can be stored via inside any of the folder on the system hard drive and has no relations with any Jobs. The las, by contrast, is stored in the predefined Media Storage Location and belongs to a specific Job. It helps for grouping them, as well as for reporting and analysis purposes.

Independent Snapshots

To take an Independent Snapshot, stop a Job if there is any, then click on the camera button on the Job Control Tool Bar of either displays to capture the frame. Finally, specify a location where the image file should be stored. ICON™ software will show a notification with the snapshot's thumbnail.

In-Job Snapshots

To take an In-Job Snapshot, start a Job if there is not any. If the operator has Job Management -> Enable Snapshot Tag Data Entry set to OFF, the further process is like taking an Independent Snapshot. Otherwise, after clicking on  button, fill in the necessary sections in the pop-up dialog window, and click OK to complete.



TAG DATA ENTRY DIALOG BOX

Note: The tag and comments are tied to the Job when OK is pressed. Pressing OK is required even with no text entered. The tag data will be saved in the database and can be selected again from the Tag Title combo box.

Export Snapshots

ICON™ software provides two modes of snapshot export, Automatic and Manual. Refer to the ICON™ Backstage -> Settings -> Preferences -> Export section to select the default mode and the desired export location.

Automatic Snapshot Export

All the snapshots will be exported automatically to the default export location automatically whenever the job being stopped.

Manual Snapshot Export

To manually export snapshots and learn more about Video Export Manager, refer to the ICON™ Backstage -> Export section.

Toggling Overlay

This option is only available for a Video being recorded. To turn the Integrated (Default) Overlay ON, click on button located on the Job Control Tool Bar of either displays. The Its pattern will change to and the correspondent indicator will appear on the display. To turn the Integrated (Default) Overlay OFF, click on the button again. Repeat these actions as desired. When the camera currently mapped to the display is not recording, the button is disabled.

Note: The Integrated (Default) Overlay is not visible on the Video Panel, but if it is ON it will be displayed in exported videos for the that time.

The Integrated (Default) Overlay can be turned on automatically each time when the Video starts being recorded.

Refer to the ICON™ Backstage -> Settings -> Preferences -> User Interaction section to select this option. The operator can turn the overlay ON and OFF at any time. Turning the overlay OFF manually is not required as it will be automatically turned OFF when the Video stops being recorded.

Exporting Video with Overlay

To apply the current Integrated (Default) Overlay from the beginning until the end of the, complete the following steps:

1. Navigate to Backstage -> Settings -> Preferences -> Export.
2. Set the option Set Automatic Video Overlay Source to Template Annotations Only.
3. Set the option Set Automatic Video Overlay Template to Icon Default Overlay

To apply the Integrated (Default) Overlay as it used to be at the time of video recording and for the time it was ON only:

1. Navigate to Backstage -> Settings -> Preferences -> Export.
2. Set the option Set Automatic Video Overlay Source to Video Annotations Only.
3. If an overlay template has been applied to the video during recording, the exported video will display annotations.


Managing Recorded Jobs

Deleting Recorded Jobs

Caution: Deleting Jobs is an irreversible operation. They cannot be undeleted, and all videos, snapshots, tags, and telemetry data related to those Jobs will be lost.

Deleting An Individual Job


To delete a single recorded Job in Video Export Manager, select the Job you want to delete from the Recorded Jobs list. Beside the Job title, click the trash button and confirm the action.



DELETING A SINGLE JOB

Deleting Multiple Jobs

ICON™ software provides the option to delete multiple Jobs at a time. In Video Export Manager, click Multi Select and then check the checkbox in front of the Job requiring deletion. Click the Delete button at the top and confirm the action.




DELETING MULTIPLE JOBS

Transferring Recorded Jobs

ICON™ software allows Jobs to be transferred from one computer to another individually or as a group. The process of selecting Jobs for transferring is like of selecting them for deleting. Refer to the Deleting Recording Jobs section above for more details.

Exporting Jobs


To export an individual or a group of Jobs, complete the following steps:

1. Navigate to Backstage -> Export.
2. Select a Job/Jobs to be exported from the Recorded Jobs list.
3. Click  button beside the Job title in case of a single job or the Transfer button at the top to start exporting.
4. Choose a folder in the File Explore where to export the encapsulated Job (*.ijob) file(s) on the computer.
5. Answer whether the original Job(s) must be removed from the system. Click Yes if you want to delete original files when exporting.

Importing Jobs


1. To import a Job, complete the following steps:
2. Navigate to Backstage -> Export.
3. Click the Import button on the top.
4. In the 'Open File' dialog, choose the Job (*.ijob) file to be imported from the disk drive. Getting Job Telemetry Data.

Getting Job Telemetry



SELECTING TELEMTRY DATA

ICON™ software allows to retrieve a Job telemetry data for analysis and reporting purposes as a *.csv file. This operation does not affect neither any of a Job-related data nor the Job itself. To get a Job data, complete the following steps:

1. Navigate to Backstage -> Export.
2. Select a Job/Jobs to get data from the Recorded Jobs list.
3. Click  button beside the Job title.
4. In the popped-up dialog, select all the devices and their parameters to be retrieved.


5. Click Ok.
6. In the standard Windows ‘Save File as...’ dialog, enter a file name to store the data.
7. Click Save.

Xbox Controller

To use the Xbox controller, the operator must be in a user group with the preference Group Preferences -> Gamepad Controller -> Gamepad Control Access set to ON.

ICON™ software will ignore the Xbox controller otherwise. Refer to the ICON™ Backstage -> User Group -> Group Preferences section for more detail.

Connecting the Xbox Controller

Plug the Xbox controller’s USB cable into an available USB port on the computer or interface box. Once the controller is connected, ICON™ software will post to the Notification Panel and show  icon on the System Status Panel indicating that the controller is connected.


Note: A driver may need to be installed depending on the Windows system configuration.

Control Mapping

Xbox controller mapping depends on the Gamepad Profile assigned to a user group. Refer to the ICON™ Backstage -> Settings -> Gamepad Profile Manager for more details on how to create and map a gamepad.

Note: The available functions that an Xbox controller control element can be mapped to depend on the nature of the element. The buttons on an Xbox controller can be separated into two distinct categories:


1. **Digital** - type buttons have only a pressed or released status – ON or OFF.
2. **Analog** type buttons, however, are dynamic with increased touch or motion. Analog buttons include the left and right trigger and the left and right thumb sticks. As a result, for example, the left and right triggers can only be used to control a camera’s zoom function or move actuators.



GAMEPAD LAYOUT

Xbox Controller Settings

ICON™ software allows each user group to have their own can Xbox controller's settings, the desired Gamepad Profile, the Dead Zone size and shape. Refer to the ICON™ Backstage -> User Group -> Group Preferences section for more detail.



ADJUSTING A DEAD ZONE SIZE

DEAD ZONE SIZE

When an Xbox thumb stick is centered, it is in the Dead Zone. This means that there are no signals being sent to the software. The sensitivity of the thumb stick can be changed by adjusting the Dead Zone size and type, allowing for movement before a command is sent.

DEAD ZONE SHAPES

Dead Zones can be adjusted to be Axial, Radial or None. An Axial Dead Zone covers a cross-shaped region on the thumb stick, increasing the required movement along the X-axis and Y-axis. A Radial Dead Zone has uniform margins around the center of the thumb stick. Adjustment to the margins of a Dead Zone is performed by moving the yellow dot along the slider or entering a value.

AXIAL AND RADIAL DEAD ZONE SHAPES



Keyboard Control

ICON™ software allows the operator to control the selected device via the PC keyboard. Two categories of devices are currently supported, Cameras and Chassis. To control a device, select it first. Refer to the Control and Operation section for more details. Alternatively, pressing the Tab key on the keyboard allows to transfer control from one tab on the Control Ribbon to another and select the first device in the list from each tab.

Camera Keyboard Control

Key	Command
Up Arrow ↑	Tilt Up
Down Arrow ↓	Tilt Down
Left Arrow ←	Pan Left

Right Arrow →	Pan Right
CTRL + ↑	Zoom Tele
CTRL + ↓	Zoom Wide
Shift + CTRL + ↑	Increase Light Intensity
Shift + CTRL + ↓	Decrease Light Intensity
Esc	Center Joystick and Stop Pan/Tilt

Note: Releasing the key will not reset the joystick and sliders back to center position, like the mouse or gamepad control does. The joystick and the sliders will be locked in place to give continuous command. Press Esc button or manually set the joystick or slider to center to stop the operation. Track Keyboard Control

TRACK KEYBOARD CONTROL	
Key	Command
Up Arrow ↑	Throttle Forward
Down Arrow ↓	Throttle Backward
Left Arrow ←	Steer Left
Right Arrow →	Steer Right
Esc	Center Throttle and Stop Steer

Note: Releasing the key will not reset the throttle and steering sliders back to center position, like the mouse or gamepad control does. Press Esc or manually set the sliders to the center to stop the operation.

System Status Panels


The System Communication Channel Status Panel shows the status of each communication channels in the system. The color of the icon indicates the working status of the communication channel.



SYSTEM COMMUNICATION CHANNEL STATUS PANEL

Green - the communication port is opened, and the communication packets are transmitting normally.
 Orange - the communication port is open, but there are no packets transmitted or received. It is usually caused by no devices that can be discovered and initialized on this channel due to any reason.
 Red - the communication port is closed or failed – no communication is established.
 Besides the indicators for the whole channel, ICON™ software also has an individual System Device Status Panel indicator for each device that has Device Control tile on the Control Panel. The indicators are located at the upper-right corner of the tile.

Green – at least 80% of packets transmitted to this device are acknowledged.
Orange – from 60 to 80% of packets transmitted to this device are acknowledged. The device can still be controllable.
Red – less than 60% of packets transmitted to this device are acknowledged. The device is likely to be uncontrollable.
Blue – unknown status. No attempts to communicate with the device were made.



SYSTEM DEVICE STATUS PANEL

ICON™ Reporting

ICON™ software has a robust SQL database that stores data and information collected in an ICON job container. As a standard feature within ICON™ the information can be exported (see the exports section on page [16]) from the backstage as:

- The job data as a CSV file containing the data values collected in the job.
- Video collected in the job.
- Snapshot pictures collected in the job.

Alternatively SQL based reports can be created with customized formats collating data, still pictures, and snapshot information. These SQL based reports are not a standard feature but can be enabled on ICON™ PRO versions as integration service. There is a onetime setup fee associated with configuring the reporting services and a basic default report. Additional customized reports can be developed if required. The cost for customized reports will vary depending on the complexity.

The reports provided can be exported in a PDF format or to Microsoft Word format for further customization if required.

Troubleshooting

Refer to ICON Troubleshooting Guide.

Parts and repairs

Ordering Parts/Customer Service

Spare or replacement parts are available and can be ordered directly from your local office.

When ordering parts, you will have to provide the original sales order acknowledgement (SOA) number. A serial number of a system component can also be used for identification purposes.

- XML and mirror files are available from the factory with provision of your system serial number.

Eddyfi Robotics Ltd. (Nanaimo Location)
2569 Kenworth Road, Suite C Nanaimo, BC, V9T 3M4 CANADA
TF 1.877.468.5886
T +1.250.729.8080
info@eddyfi.com www.eddyfitechnologies.com

Eddyfi Robotics – US (American Authorized Distributor and Service Centre)
812 W 13th Street Deer Park, TX, 77536 USA
T +1.281.542.3292
info@eddyfi.com
info@eddyfi.com www.eddyfitechnologies.com

Warranty Repairs

Warranty conditions are specified in the Warranty section. Should any conditions of the manufacturer's warranty be breached, the warranty may be considered void. All returned items must be sent prepaid to Eddyfi Technologies at the above address.

Factory Returns to Canada

Some sub-assemblies of your Eddyfi Technologies product are not field-serviceable and may need to return to the factory for repair. Warranty claims must return to the factory for evaluation.

To return an item for evaluation or repair, first contact Eddyfi Technologies at our toll-free number or e-mail address. Eddyfi Technologies will supply a Return Merchandise Authorization (RMA) number with detailed shipping and customs instructions. Items shipped without an RMA number will be held at Eddyfi Technologies until the correct paperwork is completed. If cross-border shipments are not labelled as per the instructions, the items may be held by customs and issued additional fees.

All returned items must be sent prepaid unless other specific arrangements have been made.

When the product or system is being shipped anywhere by courier or shipping company, it must be packaged in the original packaging it was received in. This measure greatly reduces the consequences of rough handling and subsequent shipping damage.

Eddyfi Technologies cannot be held responsible for damages due to improper packaging. Shipping damage may have significant impact on repair turnaround times.

Limited warranty policy

Refer the Eddyfi Technologies website for warranty terms for this product. <https://www.eddyfi.com/en/salesterms>

The information in this document is accurate as of its publication. Actual products may differ from those presented herein.

© 2024 Eddyfi Canada, Inc. Ectane, and their associated logos are trademarks or registered trademarks of Eddyfi Canada, Inc. in the United States and/or other countries. Eddyfi Technologies reserves the right to change product offerings and specifications without notice. Eddyfi Technologies is a Previa Business Unit.

www.eddyfi.com

info@eddyfi.com



**Eddyfi
Technologies**
Beyond current